Technical Documentation



VISY-X

VISY-Command WEB Retrofit Display



Version: 1

Edition: 2022-09 Art. no.: 350379



Table of Contents

| 1 | Overview | 1 |
|-----|-----------------------------------|---|
| 2 | Scope of Delivery | 2 |
| 3 | Installation | 3 |
| 3.1 | VISY-Command WEB with Front Plate | 3 |
| 3.2 | Front Plate Dismantling | 4 |
| 3.3 | SECON Display Mounting | 5 |

I Contents



1 Overview

VISY-Command WEB is the evaluation unit available with an integrated display that shows locally the current tank data, delivery data and various alarms that are recorded by the VISY-X system. In addition, the VISY-Command WEB has SECON-X functionality which makes remote monitoring possible along with a SECON server.

This manual describes how to retrofit the **SECON display** to a VISY-Command WEB with front plate using the conversion kit.

The conversion kit can be ordered at FAFNIR with article number 902001.

Overview Page 1/6



2 Scope of Delivery



SECON Display

 Display for VISY-Command Web fixed in a plastic frame

Cable ties

Page 2/6 Scope of Delivery




3 Installation



Disconnect the VISY-Command WEB from power supply before opening the housing and protect it against reconnection, as well as determine the absence of voltage on all poles.

3.1 VISY-Command WEB with Front Plate




(1) Unlock the VISY-Command Web with the housing key and open the housing door.

Installation Page 3/6




3.2 Front Plate Dismantling

(1) Unplug the earthing cable connected to the nut of the front plate's backside.



(2) Remove the 4 nuts from the backside of the plate and remove the plate completely from the VISY-Command Web.



Page 4/6 Installation



3.3 SECON Display Mounting

(1) Unscrew the 2 metal plates connected to the side of the display and keep it aside.




(2) Carefully insert the new display into the VISY-Command Web door and align it properly with the door. Now place the 2 metal rods plates on either side of the display and screw them onto the door so that the display is fixed on the door.



Installation Page 5/6



(3) Connect the cables to the display as shown below



(4) Final result



All cables must be secured so that they cannot lie on or fall onto the VP board.

- (5) Close the housing door and lock it with the housing key.
- (6) Mounting of the SECON display to the VISY-Command Web is now completed.

Page 6/6 Installation



| Blanl | k Pag | e |
|-------|-------|---|
|-------|-------|---|



Blank Page



Blank Page



FAFNIR GmbH Schnackenburgallee 149 c 22525 Hamburg, Germany T: +49/40/39 82 07-0

E-mail: info@fafnir.com Web: www.fafnir.com