
Technical Documentation



HPH Ex...



Edition: 2023-11 Version: 6 Article no.: 350049



Table of Contents

1	Characteristics	1
2	Safety Instructions	1
3	Installation	2
3.1	Mounting instructions	2
4	Electrical connection	3
4.1	HPH Ex d with a sensor (4 20 mA)	3
4.2	Wiring diagram HPH Ex d	5
4.3	HPH Ex i D with a sensor (4 to 20 mA)	6
4.4	Wiring diagram HPH Ex i D	8
5	Servicing	9
5.1	Return Shipment	9
6	Technical Data	9
6.1	HPH Ex and SB 1	9
7	List of Figures	10
8	Annex	11
8.1	EU Declaration of Conformity HPH Ex	11
8.2	EU-Type Examination Certificate HPH Ex	12
8.3	Instructions HPH Ex	16
8.4	EU Declaration of Conformity SB	20
8.5	EU-Type Examination Certificate SB	21
86	Instructions SB	25

© Copyright:

Reproduction and translation are permitted solely with the written consent of the FAFNIR GmbH. The FAFNIR GmbH reserves the right to carry out product alterations without prior notice.



1 Characteristics

The HPH Ex ... (High Pressure Housing) is a connection housing with type of ignition protection "Ex d" (pressure resistant encapsulation) or with type of ignition protection "Ex i" (intrinsically safe communication / supply).

The "Ex d" variant, together with the SB 1 Safety Barrier, allows intrinsically safe sensors to be supplied with non-intrinsically safe supply devices.

The "Ex i" variant has no safety barrier and can therefore only be connected to intrinsically safe supply devices.

With the optional display, the output signal of a sensor with 4 to 20 mA interface can be displayed in percent.

2 Safety Instructions

Use the HPH Ex ... and, if applicable, the SB 1 only for this purpose. The manufacturer accepts no liability for any form of damage resulting from improper use.

The HPH Ex ... and SB 1 have been developed, manufactured and tested in accordance with up to date good engineering practices and generally accepted safety standards. Nevertheless, hazards may arise from its use. For this reason, the following safety instructions must be observed:

Do not change or modify the HPH Ex ... and SB 1 or add any equipment without the prior consent of the manufacturer.

The installation, operation and maintenance of the measuring HPH Ex ... the SB 1 must be carried out only by expert personnel. Specialised knowledge must be acquired by regular training.

Operators, installers and service technicians must comply with all applicable safety regulations. This also applies to any local safety and accident prevention regulations which are not stated in this guide.

The safety instructions in this guide are marked as follows:



If these safety instructions are not observed, it may result in the risk of accident or damages to the devices.

HPH Ex... - Characteristics Page 1/28



3 Installation



When installing and operating the HPH Ex ... and SB1 in potentially explosive areas, the requirements of the Explosion Protection Regulations, the Industrial Health and Safety Regulations and the Equipment Safety Regulations as well as generally accepted rules of engineering and these operating instructions must be observed. The special conditions of the EU-Type Examination Certificate must be observed.



This also applies to the local safety and accident prevention regulations which are not stated in this Instructions.



During the mounting of the HPH Ex ... and SB 1 attention must be paid not to damage a connected sensor (see the relevant documentation of the sensor).

3.1 Mounting instructions



For installation of the HPH Ex d an approved Ex d cable gland with M20 x 1.5 thread is required.



The threads must not be damaged.

Page 2/28 HPH Ex ... - Installation



4 Electrical connection

4.1 HPH Ex d with a sensor (4 ... 20 mA)

To connect the HPH Ex d unscrew the housing cover, and if applicable, pull out the display (see figure).

- (1) Loosen the locking screw (2)
- (2) Unscrew the housing cover (1)
- (3) For the version with display (3):
- Loosen the fixing screws 4
- Pull out the display (3) carefully (the connector on the display can be disconnected)
- (4) Connect the HPH (pay attention to polarity)
- (5) The external ground terminal must be connected to PA with a 4 mm² cable





Figure 1: Design of HPH Ex d





- (1) Outer ground terminal
- (2) Fuse (T5; T50 mA)
- (3) Safety barrier connector (version with display)
- 4 Inner ground terminal
- (5) Display connector
- (6) Connection terminal: left (+), right (-)
- 7 Safety barrier connector (version without display)

Figure 2: Electrical connection of the HPH Ex d

The safety barrier SB 1 has a voltage drop of max. 8 V.

The display is looped into the positive supply circuit of the sensor and has an additional voltage drop of 4 V. It cannot be configured.

The sum of both voltages must be added to the minimum supply voltage of the sensor.

The measured current is displayed from -2.5% (3.8 mA) to 103 % (20.5 mA); up to 99.9 % with 1 decimal digit, above 100 % (20 mA) without decimal digit.

The display of "ErL" (3.6 mA) or "ErH" (21.5 mA) indicates measurement errors depending on the sensor configuration.

If the probe shows "---", the current has fallen below 3.5 mA. In this case a measurement is not possible.

The plugged-in fuse (2) serves to protect the safety barrier SB 1.



4.2 Wiring diagram HPH Ex d




Figure 3: Wiring diagram for HPH Ex d and SB 1 (non-earthed power supply)




Figure 4: Wiring diagram for HPH Ex d and SB 1 (earthed power supply)



4.3 HPH Ex i D with a sensor (4 to 20 mA)

To connect the HPH Ex i D unscrew the housing cover and pull out the display (see figure).

- (1) Loosen the locking screw 2
- (2) Unscrew the housing cover (1)
- (3) Loosen the display fixing screws (4)
- (4) Pull out the display (3) carefully (the connector on the display can be disconnected)
- (5) Connect the HPH (pay attention to polarity)
- (6) The external ground terminal must be connected to PA with a 4 mm² cable





Figure 5: Design of HPH Ex i D





- ① Outer ground terminal
- (2) Inner ground terminal
- 3 Display connector
- 4) Connection terminal: left (+), right (-)

Figure 6: Electrical connection of the HPH Ex i D

The display is looped into the positive supply circuit of the sensor and has an additional voltage drop of 4 V. It cannot be configured.

This voltage must be added to the minimum supply voltage of the sensor.

The measured current is displayed from -2.5% (3.8 mA) to 103 % (20.5 mA); up to 99.9 % with 1 decimal digit, above 100 % (20 mA) without decimal digit.

The display of "ErL" (3.6 mA) or "ErH" (21.5 mA) indicates measurement errors depending on the sensor configuration.

If the probe shows "---", the current has fallen below 3.5 mA. In this case a measurement is not possible.



4.4 Wiring diagram HPH Ex i D




Figure 7: Wiring diagram HPH Ex i D (non-earthed power supply)



5 Servicing

5.1 Return Shipment

Before returning any FAFNIR equipment, the Return Material Authorization (RMA) by the FAFNIR customer service is required. Please contact your account manager or the customer service to receive the instructions on how to return goods.



The return of FAFNIR products is only possible after approval by the FAFNIR customer service.

6 Technical Data

6.1 HPH Ex ... and SB 1

Dimensions: \emptyset 95 x H 71 [mm] with display;

(without cable glands and con- Ø 95 x H 66 [mm] without display

nection unit)

Ambient temperature: -40 °C ... +85 °C

Protection class: IP68

Power supply: without display: max. 26 V

with display: max. 29 V

Voltage drop: $\leq 8 \text{ V (with safety barrier SB 1)}$

 \leq 4 V (with display)

≤12 V (with safety barrier SB 1 and display)

Accuracy: 0.1 % (4 mA ... 20 mA)

Display: 3-digit display, 10 mm high,

7 Segment LEDs

Display range: -9,9 % ... +199 %

Output signal: 4 mA ... 20 mA

HPH Ex... - Servicing Page 9/28



7 List of Figures

Figure 1: Design of HPH Ex d	3
Figure 2: Electrical connection of the HPH Ex d	
Figure 3: Wiring diagram for HPH Ex d and SB 1 (non-earthed power supply)	5
Figure 4: Wiring diagram for HPH Ex d and SB 1 (earthed power supply)	5
Figure 5: Design of HPH Ex i D	6
Figure 6: Electrical connection of the HPH Ex i D	7
Figure 7: Wiring diagram HPH Ex i D (non-earthed power supply)	8



EU-Konformitätserklärung EU Declaration of Conformity Déclaration UE de Conformité Dichiarazione di Conformità UE



FAFNIR GmbH, Deutschland / Germany / Allemagne / Germania

erklärt als Hersteller in alleiniger Verantwortung, dass das Produkt declares as manufacturer under sole responsibility that the product déclare sous sa seule responsabilité en qualité de fabricant que le produit dichiara sotto la sola responsabilità del produttore, che il prodotto

Gehäuse mit oder ohne Anzeige / Enclosure with or without Display / Boîtier avec ou sans afficheur / Custodia con o senza display

HPH ...

den Vorschriften der europäischen Richtlinien complies with the regulations of the European directives est conforme aux réglementations des directives européennes suivantes è conforme ai regolamenti delle direttive europee

2011/65/EU	Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten	RoHS
2011/65/EU	Restriction of the use of certain hazardous substances in electrical and electronic equipment	RoHS
2011/65/UE	Limitation de l'utilisation de certaines substances dangereuses dans les équipements électriques et électroniques	RoHS
2011/65/UE	Restrizione dell'uso di determinate sostanze pericolose nelle apparecchiature elettriche ed elettroniche	RoHS
2014/30/EU	Elektromagnetische Verträglichkeit	EMV
2014/30/EU	Electromagnetic compatibility	EMC
2014/30/UE	Compatibilité électromagnétique	CEM
2014/30/UE	Compatibilità elettromagnetica	CEM
2014/34/EU	Geräte und Schutzsysteme zur bestimmungsgemäßen Verwendung in explosionsgefährdeten Bereichen	ATEX
2014/34/EU	Equipment and protective systems intended for use in potentially explosive atmospheres	ATEX
2014/34/UE	Appareils et systèmes de protection destinés à être utilisés en atmosphères explosibles	ATEX
2014/34/UE	Apparecchi e sistemi di protezione destinati a essere utilizzati in atmosfera potenzialmente esplosiva	ATEX

durch die Anwendung folgender harmonisierter Normen entspricht by applying the harmonised standards par l'application des normes applicando le norme armonizzate

RoHS / RoHS / RoHS / RoHS EMV / EMC / CEM / CEM ATEX / ATEX / ATEX / ATEX EN 50581:2012 EN 61326-1:2013 EN IEC 60079-0:2018 / EN 60079-1:2014 /

EN 60079-11:2012 / EN 60079-31:2014

Das Produkt ist bestimmt als Elektro- und Elektronikgerät der RoHS-The product is determined as electrical and electronic equipment of RoHS Le produit est déterminé comme des équipements électriques et électroniques de RoHS Il prodotto è determinato come apparecchiatura elettrica ed elettronica di RoHS

Kategorie / Category / Catégorie / Categoria

Überwachungs- und Kontrollinstrumenten in der Industrie / Industrial Monitoring and Control Instruments / Instruments de contrôle et de surveillance industriels / Strumenti di monitoraggio e controllo industriali

Das Produkt entspricht den EMV-Anforderungen The product complies with the EMC requirements Le produit est conforme aux exigences CEM Il prodotto è conforme ai requisiti CEM

Störaussendung / Emission / Émission / L'emissione Störfestigkeit / Immunity / D'immunité / Immunità Klasse B / Class B / Classe B / Classe B Industrielle elektromagnetische Umgebung / Industrial electromagnetic environment / Environnement électromagnétique industriel / Ambiente elettromagnetico industriale

Die notifizierte Stelle TÜV NORD CERT GmbH, 0044 hat eine EU-Baumusterprüfung durchgeführt und folgende Bescheinigung ausgestellt The notified body TÜV NORD CERT GmbH, 0044 performed a EU-type examination and issued the certificate L'organisme notifié TÜV NORD CERT GmbH, 0044 a effectué examen UE de type et a établi l'attestation L'organismo notificato TÜV NORD CERT GmbH, 0044 ha effettuato esame UE del tipo e rilasciato il certificato

HPH Ex ...

TÜV 09 ATEX 555395 X

Hamburg, 11.11.2019
Ort, Datum / Place, Date / Lieu, Date / Luogo, data

Geschäftsführer / Managing Director / Gérant / Direttore Generale: René Albrecht

Seite / Page / Page / Pagina 1/1

Translation

(1) EU-Type Examination Certificate

(2) Equipment and protective systems intended for use in potentially explosive atmospheres, Directive 2014/34/EU





(3) Certificate Number

TÜV 09 ATEX 555395 X

issue:

00

(4) for the product:

Enclosure with or without display type HPH Ex ...

(5) of the manufacturer:

FAFNIR GmbH

(6) Address:

Schnackenburgallee 149 c, 22525 Hamburg, Germany

Order number:

8003006585

Date of issue:

2019-10-22

- (7) The design of this product and any acceptable variation thereto are specified in the schedule to this EU-Type Examination Certificate and the documents therein referred to.
- (8) The TÜV NORD CERT GmbH, Notified Body No. 0044, in accordance with Article 17 of the Directive 2014/34/EU of the European Parliament and the Council of 26 February 2014, certifies that this product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres given in Annex II to the Directive.
 The examination and test results are recorded in the confidential ATEX Assessment Report No. 19 203 246394.
- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:

EN IEC 60079-0:2018

EN 60079-1:2014

EN 60079-11:2012

EN 60079-31:2014

except in respect of those requirements listed at item 18 of the schedule.

- (10) If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions for Use specified in the schedule to this certificate.
- (11) This EU-Type Examination Certificate relates only to the design, and construction of the specified product. Further requirements of the Directive apply to the manufacturing process and supply of this equipment. These are not covered by this certificate.
- (12) The marking of the product shall include the following:

ξx See item 15 of the schedule

TÜV NORD CERT GmbH, Langemarckstraße 20, 45141 Essen, notified by the central office of the countries for safety engineering (ZLS), Ident. Nr. 0044, legal successor of the TÜV NORD CERT GmbH & Co. KG Ident. Nr. 0032

The head of the notified body

Roder

Hanover office, Am TÜV 1, 30519 Hannover, Tel. +49 511 998-61455, Fax +49 511 998-61590



(13) SCHEDULE

(14) EU-Type Examination Certificate No. TÜV 09 ATEX 555395 X issue 00

(15) Description of product

The enclosure with or without display type HPH Ex d ... is preferably used in conjunction with a certified flameproof encapsulated safety barrier, e. g. SB 1, to connect intrinsically safe sensors (two-wire) to non-intrinsically safe circuits and, if necessary, to visualise the measured value.

The enclosure with display type HPH Ex i D is preferably used in intrinsically safe sensor circuits to visualise a measured value.

In the future, the enclosure may also be manufactured in accordance with the test documents listed in the ATEX test report. The changes affect the addition of a new type and the dust explosion protection. Furthermore, the equipment was assessed according to the latest standards.

The marking is as follows:

Type HPH Ex d ...

(Ex) II 2 G Ex db IIC T6...T4 Gb resp. II 1 D Ex ta IIIC T100 °C Da

Type HPH Ex i D

(Ex) II 1 G Ex ia IIC T6...T4 Ga resp. II 1 D Ex ia IIIC T125 °C Da

Type designation:

HPH Ex d Housing in flameproof enclosure and protection by enclosure without display HPH Ex d D Housing in flameproof enclosure and protection by enclosure with display Enclosure with intrinsically safe display

Technical data:

Type HPH Ex d

Signal and supply circuit (terminal -, +)

in type of protection flameproof enclosure Ex db IIC and protection by enclosure Ex ta IIIC

 $U = 12 V_{DC} ... 26 V_{DC}$ I = 4 mA ... 20 mA

Type HPH Ex d D

Signal and supply circuit (terminal -, +)

in type of protection flameproof enclosure Ex db IIC and protection by enclosure Ex ta IIIC

 $U = 16 V_{DC} ... 29 V_{DC}$ I = 4 mA ... 20 mA



Schedule to EU-Type Examination Certificate No. TÜV 09 ATEX 555395 X issue 00

Type HPH Ex i D

Signal and supply circuit (terminal -, +)

in type of protection intrinsic safety Ex ia IIC/IIIC

Maximum values:

 $U_i = 30 V$

 I_i = 200 mA at $T_a \le +65$ °C resp. 100 mA at $T_a \le +85$ °C

 $P_i = 1 W$ $L_i = 250 \mu H$

 $C_i = 25 \, \text{nF}$

Permissible ambient temperature range:

Type HPH Ex d ...

Used as category 2G equipment

Temperature class	Ambient temperature
T6	-40 °C to +50 °C
T5	-40 °C to +65 °C
T4	-40 °C to +85 °C
T3	-40 °C to +85 °C
T2	-40 °C to +85 °C
T1	-40 °C to +85 °C

Used as category 1D equipment

Maximum surface temperature		Ambient temperature range	
dust layer ≤ 5 mm	immersed in dust	Ambient temperature range	
T _a + 15 °C	T _a + 15 °C	-40 °C to +85 °C	

Type HPH Ex i D

Used as category 1G equipment

Temperature class	Ambient temperature range
T6	-40 °C to +40 °C
T5	-40 °C to +55 °C
T4	-40 °C to +60 °C
Т3	-40 °C to +60 °C
T2	-40 °C to +60 °C
T1	-40 °C to +60 °C

The process pressure for the media must be between 0.8 bar and 1.1 bar where explosive vapourair mixtures are present. If no explosive mixtures are present, the equipment may also be operated outside this area according to the manufacturer's specification.

Used as category 2G equipment

Tomporeture alone	Ambient temp	perature range
Temperature class	at I _i ≤ 200 mA	at I _i ≤ 100 mA
Т6	-40 °C to +40 °C	-40 °C to +40 °C
T5	-40 °C to +55 °C	-40 °C to +55 °C
T4	-40 °C to +65 °C	-40 °C to +85 °C
Т3	-40 °C to +65 °C	-40 °C to +85 °C
T2	-40 °C to +65 °C	-40 °C to +85 °C
T1	-40 °C to +65 °C	-40 °C to +85 °C



Schedule to EU-Type Examination Certificate No. TÜV 09 ATEX 555395 X issue 00

Used as category 1D equipment

Maximum surface temperature		Ambient temperature range
dust layer ≤ 5 mm	Immersed in dust	Ambient temperature range
$I_i \le 200 \text{ mA: } T_a + 55 \text{ °C}$ $I_i \le 100 \text{ mA: } T_a + 40 \text{ °C}$	observe EN 60079-14	I _i ≤ 200 mA: -40 °C +65 °C I _i ≤ 100 mA: -40 °C +85 °C

All further data are valid unchanged.

- (16) Drawings and documents are listed in the ATEX Assessment Report No. 19 203 246394
- (17) Specific Conditions for Use
 - 1. If the type HPH Ex i D is mounted in a plastic enclosure, the danger of ignition by electrostatic generated by friction on the enclosure must be avoided.
 - 2. If the type HPH Ex i D is mounted in an aluminium enclosure, an ignition hazard caused by impact or friction must be avoided.
 - 3. For the electrical connection at type HPH Ex d ..., cable glands certified in the type of protection flameproof enclosure must be used.
 - 4. Repair of flameproof joints of enclosure HPH Ex d ... is not planned.
 - The equipotential bonding connection of a metallic enclosure must be connected to the equipotential bonding of the potentially explosive area (an equipotential bonding must exist for the entire intrinsically safe area).
- (18) Essential Health and Safety Requirements

no additional ones

- End of Certificate -





Instructions in accordance with directive 2014/34/EU

TÜV 09 ATEX 555395 X

Edition: 08.2019

Enclosure with or without display type HPH Ex ...

I Range of application

The enclosure with or without display type HPH Ex d ... is preferably used in conjunction with a certified flameproof encapsulated safety barrier, e.g. SB 1, to connect intrinsically safe sensors (two-wire) to non-intrinsically safe circuits and, if necessary, to visualise the measured value.

The enclosure with display type HPH Ex i D is preferably used in intrinsically safe sensor circuits to visualise a measured value.

II Standards

The equipment is designed according to the following European standards

EN IEC 60079-0:2018 Equipment – General requirements

EN 60079-1:2014 Equipment protection by flameproof enclosures "d"

EN 60079-11:2012 Equipment protection by intrinsic safety "i"

EN 60079-31:2014 Equipment dust ignition protection by enclosure "t"

III Instructions for safe ...

III.a ... use

The enclosure HPH Ex d ... is suitable for use in potentially explosive areas in Zone 1 and Zone 20 as well as for all gas groups (IIA, IIB and IIC) and all dust groups (IIIA, IIIB and IIIC).

The enclosure HPH Ex i D is suitable for use in potentially explosive areas in Zone 0 and Zone 20 as well as for all gas groups (IIA, IIB and IIC) and all dust groups (IIIA, IIIB and IIIC).

The certification applies to the following device versions

HPH Ex d Housing in flameproof enclosure and protection by enclosure without display HPH Ex d D Housing in flameproof enclosure and protection by enclosure with display

HPH Ex i D Enclosure with intrinsically safe display

III.b ... assembling and dismantling

The assembly or disassembly may only be carried out without voltage!

For HPH Ex d ... the approved cable glands must be installed in the enclosure according to the manufacturer's instructions. After wiring, the cover must be firmly screwed back onto the enclosure and secured with the M4 locking screw.

With the HPH Ex d ... a threaded hole, preferably M24 \times 1.5, can be used to accommodate an approved flameproof safety barrier. The safety barrier is then used to supply an intrinsically safe (Ex i) sensor.





III.c ... installation

The wiring may only be carried out without voltage. Special regulations such as EN 60079-14 or the local installation regulations must be observed.

To ensure that the flameproof enclosure of the HPH Ex d ... is maintained, the cable entries or entries for conduits must be approved in accordance with EN 60079-1. Two threaded holes are available for this purpose. Possible threads are:

M16 × 1.5; M20 × 1.5; M24 × 1.5; M25 × 1.5; G $\frac{3}{8}$; $\frac{1}{2}$ " NPT; $\frac{3}{4}$ " NPT

Ensure that the threads are in perfect condition.

A PA connection terminal is provided for integrating the equipment into the equipotential bonding system.

General information (see also EN 60079-14:2013, clause 6.4.1):

Metallic enclosures of intrinsically safe or energy-limited apparatus need not be connected to the equipotential bonding system, unless required by the apparatus documentation or to prevent accumulation of static charge.

III.d ... adjustment

For the operation of the apparatus, no Ex-relevant adjustments are necessary.

III.e ... putting into service

Before putting into service, all devices must be checked for correct connection and installation. The electrical supply, including the connected devices, must be checked.

III.f ... maintenance (servicing and emergency repair)

The apparatus is generally maintenance-free. In the case of a defect, this must be returned to the manufacturer or one of its representatives.

Repairs to the enclosure HPH Ex d ... may only be carried out by the manufacturer.

If the HPH Ex i D version is installed in a plastic enclosure, it may only be cleaned with a damp cloth to minimise the risk of ignition due to electrostatic charging.

The HPH Ex i D complies with the dielectric strength requirements between the intrinsically safe circuit and a metallic chassis of the display with 500 V_{AC} according to EN 60079-11, clause 6.3.13.





IV Equipment marking

1 Manufacturer: FAFNIR GmbH, 22525 Hamburg

2 Type designation: HPH Ex ...

3 Certificate number: TÜV 09 ATEX 555395 X

4 Ex marking: <u>HPH Ex d ...:</u> <u>HPH Ex i D:</u>

4a acc. to ATEX directive: 😉 II 2 G bzw. II 1 D 😉 II 1 G bzw. II 1 D

4b according to standards: Ex db IIC T6...T4 Gb Ex ia IIC T6...T4 Ga

Ex ta IIIC T100 °C Da Ex ia IIIC T125 °C Da

5 Technical data: See instructions for technical data

6 Warning marking: WARNING – DO NOT OPEN *WARNING – Potential electro-

WHEN ENERGIZED static charging hazard – See in-

structions

7 CE marking: **C €** 0044

V Technical data

The following electrical values are specified:

	HPH Ex d	HPH Ex d D	HPH Ex i D
Voltage	U = 12 V 26 V	U = 16 V 29 V	$U_{i} = 30 \text{ V}$
Current	4 mA 20 mA (Error mode: 3.6 mA / 21.5 mA)		†I _i = 200 mA / 100 mA
Power			$P_i = 1 W$

Table V.a: Electrical values of the subtypes

The external capacitance and inductance of the type HPH Ex i D are as follows

 $\begin{array}{lll} \text{Inner inductance} & L_i & \leq & 250 \ \mu\text{H} \\ \text{Inner capacitance} & C_i & \leq & 25 \ \text{nF} \end{array}$

For use in potentially explosive atmospheres, the maximum temperatures, depending on the temperature class and the category respectively equipment protection level, can be found in the following tables.

HPH Ex d ...

Temperature class	Ambient temperature T _a	
Category 2G resp. Equipment pr	protection level Gb	
T6	-40 °C +50 °C	
T5	-40 °C +65 °C	
T4, T3, T2, T1	-40 °C +85 °C	

Table V.b: Temperatures of the flameproof enclosure in potentially explosive gas atmospheres

Maximum surface temperature		Ambient temperature T	
dust layer ≤ 5 mm	Immersed in dust	Ambient temperature T _a	
Category 1D resp. Equipment protection level Da			
T _a +	15 ℃	-40 °C +85 °C	

Table V.c: Temperatures of the flameproof enclosure in potentially explosive dust atmospheres

* The warning marking is only used if type HPH Ex i D is mounted in a plastic enclosure.

FAFNIR GmbH • Schnackenburgallee 149 c • 22525 Hamburg • Tel.: +49 / (0)40 / 39 82 07-0 • www.fafnir.de • info@fafnir.de

 $^{^{\}dagger}$ The permissible input current I_{i} depends on the ambient temperature T_{a} Page 3/4





HPH Ex i D

Townsulative class	Ambient temperature T _a		
Temperature class	@ I _i ≤ 200 mA	@ I _i ≤ 100 mA	
Equipment protection level Ga			
Т6	-40 °C	. +40 °C	
T5	-40 °C +55 °C		
T4, T3, T2, T1	-40 °C +60 °C		
Equipment protection level Gb			
Т6	-40 °C +40 °C		
T5	-40 °C +55 °C		
T4, T3, T2, T1	-40 °C +65 °C	-40 °C +85 °C	

Table V.d: Temperatures of the intrinsic safety display in potentially explosive gas atmospheres For use in areas where the equipment protection level Ga is required:

The process pressure of the media must be between 0.8 bar and 1.1 bar if explosive vapour-air mixtures are present. If no explosive mixtures are present, the devices may also be operated outside this area in accordance with their manufacturer's specifications.

Maximum surface temperature		Ambient temperature T
dust layer ≤ 5 mm Immersed in dust		Ambient temperature T _a
Equipment protection level Da		
$I_i \le 200 \text{ mA: } T_a + 55 \text{ °C}$ $I_i \le 100 \text{ mA: } T_a + 40 \text{ °C}$	Observe EN 60079-14*	l _i ≤ 200 mA: -40 °C +65 °C l _i ≤ 100 mA: -40 °C +85 °C

Table V.e: Temperatures of the intrinsic safety display in potentially explosive dust atmospheres General remark (see also EN 60079-0, Clause 1):

Zone 0 resp. 20 is given only under atmospheric conditions:

Temperature range: $-20 \,^{\circ}\text{C} \dots +60 \,^{\circ}\text{C}$ Pressure range: 0,8 bar ... 1,1 bar

Oxidant: Air (oxygen content approx. 21 %)

VI Special conditions of use

- 1. If the type HPH Ex i D is mounted in a plastic enclosure, the danger of ignition by electrostatic generated by friction on the enclosure must be avoided.
- 2. If the type HPH Ex i D is mounted in an aluminium enclosure, an ignition hazard caused by impact or friction must be avoided.
- 3. For the electrical connection at type HPH Ex d ..., cable glands certified in the type of protection flameproof enclosure must be used.
- 4. Repair of flameproof joints of enclosure HPH Ex d ... is not planned.
- 5. The equipotential bonding connection of a metallic enclosure must be connected to the equipotential bonding of the potentially explosive area (an equipotential bonding must exist for the entire intrinsically safe area).

FAFNIR GmbH • Schnackenburgallee 149 c • 22525 Hamburg • Tel.: +49 / (0)40 / 39 82 07-0 • www.fafnir.de • info@fafnir.de

 $^{^{\}circ}$ Clause 5.6.3.3 of EN 60079-14:2014 can be used to assess the temperatures Page 4/4





EU-Konformitätserklärung EU Declaration of Conformity Déclaration UE de Conformité Dichiarazione di Conformità UE

FAFNIR GmbH
Schnackenburgallee 149 c
22525 Hamburg
Deutschland / Germany / Allemagne / Germania

erklärt als Hersteller in alleiniger Verantwortung, dass das Produkt declares as manufacturer under sole responsibility that the product déclare sous sa seule responsabilité en qualité de fabricant que le produit dichiara sotto la sola responsabilità del produttore, che il prodotto

Sicherheitsbarriere / Safety Barrier / Barrière de sécurité / Barriera di sicurezza

SB ...

den Vorschriften der europäischen Richtlinien complies with the regulations of the European directives est conforme aux réglementations des directives européennes suivantes è conforme ai regolamenti delle direttive europee

2011/65/EU	Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten	RoHS
2011/65/EU	Restriction of the use of certain hazardous substances in electrical and electronic equipment	RoHS
2011/65/UE	Limitation de l'utilisation de certaines substances dangereuses dans les équipements électriques et électroniques	RoHS
2011/65/UE	Restrizione dell'uso di determinate sostanze pericolose nelle apparecchiature elettriche ed elettroniche	RoHS
2014/34/EU	Geräte und Schutzsysteme zur bestimmungsgemäßen Verwendung in explosionsgefährdeten Bereichen	ATEX
2014/34/EU	Equipment and protective systems intended for use in potentially explosive atmospheres	ATEX
2014/34/UE	Appareils et systèmes de protection destinés à être utilisés en atmosphères explosibles	ATEX
2014/34/UE	Apparecchi e sistemi di protezione destinati a essere utilizzati in atmosfera potenzialmente esplosiva	ATEX

durch die Anwendung folgender harmonisierter Normen entspricht by applying the harmonised standards par l'application des normes applicando le norme armonizzate

RoHS / RoHS / RoHS / RoHS ATEX / ATEX / ATEX / ATEX EN 50581:2012 EN 60079-0:2012 + A11:2013 EN 60079-1:2014 EN 60079-11:2012 EN 60079-31:2014

Das Produkt ist bestimmt als Elektro- und Elektronikgerät der RoHS-The product is determined as electrical and electronic equipment of RoHS Le produit est déterminé comme des équipements électriques et électroniques de RoHS Il prodotto è determinato come apparecchiatura elettrica ed elettronica di RoHS

Kategorie / Category / Catégorie / Categoria

Überwachungs- und Kontrollinstrumenten in der Industrie / Industrial Monitoring and Control Instruments / Instruments de contrôle et de surveillance industriels / Strumenti di monitoraggio e controllo industriali

Die notifizierte Stelle TÜV NORD CERT GmbH, 0044 hat eine EU-Baumusterprüfung durchgeführt und folgende Bescheinigung ausgestellt The notified body TÜV NORD CERT GmbH, 0044 performed a EU-type examination and issued the certificate L'organisme notifié TÜV NORD CERT GmbH, 0044 a effectué examen UE de type et a établi l'attestation L'organismo notificato TÜV NORD CERT GmbH, 0044 ha effettuato esame UE del tipo e rilasciato il certificato

SB ...

TÜV 10 ATEX 381296 X

Hamburg, 28.08.2019

Ort, Datum / Place, Date / Lieu, Date / Luogo, data

Geschäftsführer / Managing Director / Gérant / Direttore Generale: René Albrecht

Translation

(1) EU-Type Examination Certificate

(2) Equipment and protective systems intended for use in potentially explosive atmospheres, **Directive 2014/34/EU**





(3) Certificate Number

TÜV 10 ATEX 381296 X

issue: 00

(4) for the product:

Safety Barrier type SB ...

(5) of the manufacturer:

FAFNIR GmbH

(6) Address:

Schnackenburgallee 149 c, 22525 Hamburg, Germany

Order number:

8003002010

Date of issue:

2019-05-23

- (7) The design of this product and any acceptable variation thereto are specified in the schedule to this EU-Type Examination Certificate and the documents therein referred to.
- (8) The TÜV NORD CERT GmbH, Notified Body No. 0044, in accordance with Article 17 of the Directive 2014/34/EU of the European Parliament and the Council of 26 February 2014, certifies that this product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres given in Annex II to the Directive.
 The examination and test results are recorded in the confidential ATEX Assessment Report No. 19 203 237353.
- (9) Compliance with the Essential Health and Safety Requirements has been assured by compliance with:

EN 60079-0:2012 + A11:2013 EN 60079-1:2014 EN 60079-11:2012 EN 60079-31:2014 except in respect of those requirements listed at item 18 of the schedule.

- (10) If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions for Use specified in the schedule to this certificate.
- (11) This EU-Type Examination Certificate relates only to the design, and construction of the specified product. Further requirements of the Directive apply to the manufacturing process and supply of this equipment. These are not covered by this certificate.
- (12) The marking of the product shall include the following:

 (ξx) See item 15 of the schedule

TÜV NORD CERT GmbH, Langemarckstraße 20, 45141 Essen, notified by the central office of the countries for safety engineering (ZLS), Ident. Nr. 0044, legal successor of the TÜV NORD CERT GmbH & Co. KG Ident. Nr. 0032

The head of the notified body

Rode

Hanover office, Am TÜV 1, 30519 Hannover, Tel. +49 511 998-61455, Fax +49 511 998-61590



(13) SCHEDULE

(14) EU-Type Examination Certificate No. TÜV 10 ATEX 381296 X issue 00

(15) Description of product

The safety barrier type SB 1 is preferably used in conjunction with a certified flameproof enclosure, e.g. HPH Ex d ..., for connecting intrinsically safe sensors (two-wire) to non-intrinsically safe circuits. The safety barrier type SB 3 is used to connect intrinsically safe sensors (four-wire) to non-intrinsically safe circuits.

In the future, the safety barriers may also be manufactured in accordance with the test documents listed in the ATEX test report. The changes affect the addition of a new type and the dust explosion protection. Furthermore, the equipment was assessed according to the latest standards.

The marking is as follows:

Type SB 1

(Ex) II 2(1) G Ex db [ia Ga] IIC T6...T4 Gb resp. II 1(1) D Ex ta [ia Da] IIIC T115 °C Da

Type SB 3

(Ex) II (1) G [Ex ia Ga] IIC resp. II (1) D [Ex ia Da] IIIC

Type designation:

SB 1 Single-channel safety barrier potted in a bushing SB 3 Three-channel safety barrier in the wall housing

Technical data:

Type SB 1

Supply circuit $U = 24 V_{DC}$ $U_m = 253 V$

Output circuit

in type of protection "Intrinsic Safety" Ex ia IIC/IIB/IIIC

Maximum values: $U_o = 28.4 \text{ V}$ $I_o = 100 \text{ mA}$ $P_i = 705 \text{ mW}$

Characteristic line: linear

Maximum permissible outer capacitance and inductance.

	Ex ia IIC		Ex ia IIB/IIIC	
Lo	500 µH	560 µH	5 mH	2 mH
Co	71 nF	68 nF	330 nF	400 nF



Schedule to EU-Type Examination Certificate No. TÜV 10 ATEX 381296 X issue 00

Type SB 3

Supply circuit

 $U = 24 V_{DC}$ for channel 1

 $U = 5 V_{DC}$ for channel 2 and 3

 $U_{m} = 253 V$

Output circuit

in type of protection "Intrinsic Safety" Ex ia IIC/IIB/IIIC

Maximum values: U_o = 28.4 V

 $I_o = 95 \text{ mA}$ $P_i = 507 \text{ mW}$

Characteristic line: linear

Maximum permissible outer capacitance and inductance:

	Exi	a IIC	Ex ia l	IIB/IIIC
Lo	500 µH	200 μΗ	5 mH	2 mH
Co	72 nF	79 nF	340 nF	410 nF

Permissible ambient temperature range:

The ambient temperature range for SB 3 is -40 °C to +70 °C.

The ambient temperature range for SB 1 is

Used as Category 2G equipment

Temperature class	Ambient temperature
T6	-40 °C to +40 °C
T5	-40 °C to +55 °C
T4	-40 °C to +85 °C
T3	-40 °C to +85 °C
T2	-40 °C to +85 °C
T1	-40 °C to +85 °C

Used as Category 1D equipment

Maximum surfa	ce temperature	Ambient temperature
dust layer ≤ 5 mm	dust layer ≤ 5 mm Immersed in dust	
+115 °C	+115 °C	-40 °C to +85 °C

All further data are valid unchanged.

(16) Drawings and documents are listed in the ATEX Assessment Report No. 19 203 237353



Schedule to EU-Type Examination Certificate No. TÜV 10 ATEX 381296 X issue 00

(17) Specific Conditions for Use

- 1. The side of the safety barrier SB 1, where the encapsulation can be seen, must be operated protected against UV light.
- 2. The safety barrier SB 1 has no terminal compartment. It must be installed in an enclosure that corresponds to a suitable type of protection. In addition, it can only be installed in zone 1 in conjunction with a flameproof enclosure (such as HPH Ex d ...).

3. Repair of flameproof joints of SB 1 is not planned.

- 4. The equipotential bonding connection must be connected to the equipotential bonding of the potentially explosive area (an equipotential bonding must exist for the entire intrinsically safe area). Therefore, the safety barriers do not meet the dielectric strength requirements. When carrying out an insulation test on the intrinsically safe circuit, the device must therefore be disconnected from equipotential bonding.
- 5. The maximum permissible pressure of SB 1 is 30 bar.
- (18) Essential Health and Safety Requirements

no additional ones

- End of Certificate -





Edition: 05.2019

Instructions in accordance with directive 2014/34/EU

Safety Barrier type SB ...

I Range of application

The safety barrier type SB 1 is preferably used in conjunction with a certified flameproof enclosure, e.g. HPH Ex d ..., for the connection of intrinsically safe sensors (two-wire) to non-intrinsically safe circuits.

The safety barrier type SB 3 is used to connect intrinsically safe sensors (four-wire) to non-intrinsically safe circuits.

II Standards

The safety barriers are designed according to the following European standards

EN 60079-0:2012 + A11:2013 Equipment – General requirements

EN 60079-1:2014 Equipment protection by flameproof enclosures "d"

EN 60079-11:2012 Equipment protection by intrinsic safety "i"

EN 60079-31:2014 Equipment dust ignition protection by enclosure "t"

III Instructions for safe ...

III.a ... use

The safety barrier type SB 1 serves as flameproof encapsulated intrinsically safe equipment and is suitable for use in hazardous areas. The safety barrier type SB 3 serves as associated equipment and is not suitable for use in hazardous areas. The intrinsically safe sensor circuits may be routed into Zone 0 or Zone 20 and can be used for all gas groups or dust groups.

The approval applies to the following device versions

- SB 1 Single channel safety barrier potted in a bushing
- SB 3 Three-channel safety barrier in a wall enclosure

III.b ... assembling and dismantling

The assembly or disassembly may only be carried out without voltage!

Only the dismantling of the wall enclosure is intended so that the safety barrier type SB 3 can be installed. After installation, the enclosure must be closed again.

III.c ... installation

The wiring may only be done de-energized. Special regulations e.g. EN 60079-14 or the local installation regulations must be observed.

When wiring from intrinsically safe equipment to a safety barrier (preferably blue cable), the inductance and capacitance permitted under point V must not be exceeded.

SB 1

The external thread M24 \times 1.5 on the input side is preferably intended for screwing into an approved flameproof enclosure. The connection of an intrinsically safe sensor (output) takes place via an external thread M28 \times 1.5. The safety barrier can be installed in approved flameproof enclosures. When installing in an enclosure, make sure that there is a clearance and creepage distance of \times 50 mm between the input and output terminals.

Three individual cables are provided for the connection of the non-intrinsically safe auxiliary energy. The green-yellow cable must be securely connected to the equipotential bonding (PA). The supply voltage is connected to the blue (-) and red (+) cable.

The intrinsically safe output has two cables (blue and red) to which an intrinsically safe sensor is connected.

Page 1/4





The enclosure of the safety barrier is not connected to the circuit. It must therefore be installed in a metallic enclosure which is integrated in the equipotential bonding system.

The side of the safety barrier SB 1 on which the potting can be seen must be operated protected from light (e.g. daylight, artificial lighting).

SB 3

The safety barrier is suitable for wall mounting and must be installed outside the hazardous area.

The safety barrier is provided with connection terminals at the input and output. The non-intrinsically safe input side is provided with a non-blue cable gland and the intrinsically safe output side with a light blue cable gland. The safety barrier must be integrated into the equipotential bonding system. A connection terminal is provided on the outside of the enclosure for this purpose.

III.d ... adjustment

No Ex-relevant adjustments are required to operate the safety barriers.

III.e ... putting into service

Before putting into service, all devices must be checked for correct connection and installation. The electrical supply, including the connected devices, must be checked.

III.f ... maintenance (servicing and emergency repair)

The apparatus is generally maintenance-free. In the case of a defect, this must be returned to the manufacturer or one of its representatives.

There is non-compliance with the dielectric strength requirements according to EN 60079-11, Clause 6.3.13 of the safety barriers.

SB₁

The repair of the flameproof joints (M24 external thread) is not intended.

SB 3

If a fuse is defective, it may be replaced. It must be ensured that the following fuse values are adhered to (values are also on the type plate):

Nominal current $I_n \leq 32 \text{ mA}$ Breaking Capacity $I_{BC} \geq 35 \text{ A}$ Melting Integral $I^2t \leq 0,004 \text{ A}^2s$

IV Equipment marking

1 Manufacturer: FAFNIR GmbH, 22525 Hamburg

2 Type designation: SB ...

3 Certificate number: TÜV 10 ATEX 381296 X

4 Ex marking:

II 1(1) D Ex ta [ia Da] IIIC T115 °C Da

SB 3 (Ex) II (1) G [Ex ia Ga] IIC
II (1) D [Ex ia Da] IIIC

5 CE marking: $\mathbf{C} \in \mathbf{O}_{0.04}$

6 Technical data: See instructions for technical data

7 Thread size and type (only SB 1): M24





V Technical data

The nominal voltage for SB 1 and SB 3, channel 1 is:

$$U = 24 V_{DC}$$

The nominal voltage for SB 3, channel 2 (A) and channel 3 (B) is:

$$U = 5 V_{DC}$$

The maximum safety voltage is:

$$U_m = 253 V$$

The sensor circuits are designed in the ignition protection type "intrinsic safety" (ia) with a linear output characteristic. The output values per circuit are as follows

		SB 1	SB 3
Output voltage	U₀ ≤	28.4	V
Output current	I₀ ≤	99.5 mA	95.5 mA
Output power	P _o ≤	705 mW	507 mW
Inner inductance	L_i	negligib	e small
Inner capacitance	C_i	negligib	e small

The permissible external inductance and capacitance are as follows:

IIC	•	SI	B 1	SE	3
L_{o}	\leq	500 μΗ	560 µH	500 μH	200 μΗ
C_o	\leq	71 nF	68 nF	72 nF	79 nF
IIB/II	IIC				
L_{o}	\leq	5 mH	2 mH	5 mH	2 mH
C_o	\leq	330 nF	400 nF	340 nF	410 nF

The maximum values of the value pairs may be used simultaneously as concentrated capacitance and concentrated inductance.

The data of the Ex d connection thread of the SB 1 on the input side are as follows:

Thread size: M24
Thread pitch: 1,5
Tolerance: 6g
Turns: 8
Screw-in depth: 16 mm

The maximum permissible explosion pressure which may act on the SB 1 safety barrier is as follows:

$$p_{max}(SB 1) = 30 bar$$





The safety barriers may be used in the following ambient temperature range:

Type SB 1

Temperature Class	Ambient Temperature T _a	
Category 2G resp. Equipment Pr	rotection Level Gb	
T6	-40 °C +40 °C	
T5	-40 °C +55 °C	
T4, T3, T2, T1	-40 °C +85 °C	

Table 1: Service temperatures for potential explosive gas atmospheres

Maximum Surfa	Ambient Temperature T		
dust layer ≤ 5 mm immersed in dust		Ambient Temperature T _a	
Category 1D resp. Equipment Protection Level Da			
+115 °C	+115 °C	-40 °C +85 °C	

Table 2: Service temperatures for potential explosive dust atmospheres

Type SB 3

$$T_a(SB 3) = -40 \, ^{\circ}C ... + 70 \, ^{\circ}C$$

The safety barriers achieve a degree of protection of the housing of:

SB 1: IP68 SB 3: IP67

VI Special conditions of use

- 1. The side of the safety barrier SB 1, where the encapsulation can be seen, must be operated protected against UV light.
- 2. The safety barrier SB 1 has no terminal compartment. It must be installed in an enclosure that corresponds to a suitable type of protection. In addition, it can only be installed in zone 1 in conjunction with a flameproof enclosure (such as HPH Ex d ...).
- 3. Repair of flameproof joints of SB 1 is not planned.
- 4. The equipotential bonding connection must be connected to the equipotential bonding of the potentially explosive area (an equipotential bonding must exist for the entire intrinsically safe area). Therefore, the safety barriers do not meet the dielectric strength requirements. When carrying out an insulation test on the intrinsically safe circuit, the device must therefore be disconnected from equipotential bonding.
- 5. The maximum permissible pressure of SB 1 is 30 bar.



Blank P	age
---------	-----



FAFNIR GmbH Schnackenburgallee 149 c 22525 Hamburg, Germany T: +49 / 40 / 39 82 07-0

F: +49 / 40 / 390 63 39 E-mail: info@fafnir.com Web: www.fafnir.com