

FAFNIR Universal Device Protocol

Edition: 02/2018
Version: 1.09
Article no.: 350052

Protocol Version	Modification	Date	Name
1.00	First release	2010-11-30	KR
1.01	Chapter 4, added new Device Type for VISY-Stick Oil Separator. Chapter 6.2, Device Type 'f' added to ID 'p' (Product Level). Chapter 6.2, Device Types 'b', 'c', 'd' and 'f' added to ID 'w' (Water Level).	2011-05-13	KR
1.02	Chapter 5 (Status Of Device), deleted. Chapter 3, format of request and response messages changed, checksum values added in the examples. Chapter 5.1, ID 'p' (Protocol Version), format changed. Chapter 5.2, ID '=' (Status Of Device), now defined as part of the Dynamic Data IDs. Chapter 5.2, ID 't' (Temperature), deleted Device Types 'b', 'c' and 'd'. Chapter 5.2, ID 'w' (Water Level), added notes for Device Types 'b', 'c' and 'd'. Chapter 6, added Pascal and Visual Basic examples for CRC calculation.	2011-06-01	UN, KR, WS, CM
1.03	Chapter 5.1, ID 'u' (Device Sub-Type), added Sub-Type 4 (Flex) for Device Type 'a'.	2011-07-01	KR, CM
1.04	Chapter 4, added new Device Type 'p' for Pressure Sensor. Chapter 5.1, ID 'd' (Position Of Density Module), corrected the note for the case that more than one Density Module is configured. Chapter 5.2, added Dynamic Data ID 'i' (Pressure) for Device Type 'p'. Chapter 5.2, ID 'p' (Product Level), added note for Device Type 'a'. Chapter 5.2, ID 'w' (Water Level), added note for Device Type 'a'.	2011-11-30	KR, CM
1.05	Attachment A, added Delphi routine with string. Chapter 5.1, ID 'u' (Device Sub-Type), added Sub-Type 1 (VPS-V) and Sub-Type 2 (VPS-L) for Device Type 'p'. Chapter 5.2, ID 't' (Temperature), added Device Type 'p'.	2012-08-28	KR, MO
1.06	Chapter 2, added missing information and re-arranged chapter. Chapter 3, inserted new Chapter 3.1 (General message structure) Chapter 3.2, divided into sub-chapters 3.2.1 (Read Static Data) and 3.2.2 (Write Static Data). Chapter 3.3, divided into sub-chapters 3.3.1 (Read Dynamic Data) and 3.3.2 (Write Dynamic Data). Chapter 4, added new Device Type 'i' for VISY-Input. Chapter 4, added new Device Type 'o' for VISY-Output. Chapter 5.1, added Static Data ID 'h' (Hold Time After Communication Loss) for Device Type 'o'. Chapter 5.1, added Static Data ID 'o' (Option Flags) for Device Type 'o'. Chapter 5.2, removed Status '?' for Dynamic Data ID '=' (Status Of Device). Chapter 5.2, added Dynamic Data ID 'c' (Channel State) for Device Types 'i' and 'o'. Chapter 7, added Attachment B – Supported data fields.	2013-01-22	KR, WS, CM, UN
1.07	Chapter 5.1, Static Data ID 'u' (Device Sub-Type), added Sub-Type 3 (VPS-T) for Device Type 'p'. Chapter 5.2, Dynamic Data ID 'i' (Pressure), corrected resolution and example.	2015-09-01	KR
1.08	Chapter 4, added new Device Type 's' for VISY-Sludge. Chapter 5.1, added Static Data ID 's' (Maximum Distance) for Device Type 's'. Chapter 5.2, added Dynamic Data ID 's' (Distance) for Device Type 's'. Chapter 5.2, ID 't' (Temperature), added Device Type 's'. Chapter 5.2, ID 'e' (Event), added an event for Device Type 's'. Chapter 7, Attachment B, added data fields for VISY-Sludge.	2016-09-16	KR
1.09	Chapter 3, added text regarding probes that are directly connected (without a multiplexer). Chapter 4, added TORRIX ... to Device Type 'a'. Chapter 4, added new Device Type 't' for VISY-Temp Chapter 5.1, ID 't' (Position Of Temperature Sensor), added Device Type 't'. Chapter 5.2, ID 'p' (Product Level), changed note for Device Type 'f'. Chapter 5.2, ID 't' (Temperature), added Device Type 't'. Chapter 7, Attachment B, added data fields for VISY-Temp.	2018-02-20	KR



Table of contents

FAFNIR Universal Device Protocol.....	1
1 Interface	5
2 Abbreviations and formats	5
3 Message dialogues	6
3.1 General message structure.....	6
3.2 Static data	8
3.2.1 Read static data	8
3.2.2 Write static data	9
3.3 Dynamic data	10
3.3.1 Read dynamic data	10
3.3.2 Write dynamic data	11
4 Device types	13
5 Data fields	14
5.1 Static data fields	14
5.2 Dynamic data fields	20
6 Attachment A – CRC calculation	26
7 Attachment B – Supported data fields	30

1 Interface

Modulation: RS-485
Signals: A, B, GND
Mode: Asynchronous, half duplex
Baud rate: 1200 bps / 4800 bps
Start-bits: 1
Data-bits: 8
Stop-bits: 1
Parity: -

Timing conditions:

The time to transmit one character depends on the baud rate (4800 bps: 2 ms, 1200 bps: 8 ms). Since the processing time for the answer or the next command can be assumed to be the same for both speeds, timeouts are doubled for 1200 bps and set into brackets.

If the first character of the response is not received within 50 ms (100 ms) or more, the next command can be send. The transmission should be continuous. The inter-character delay must be shorter than 20 ms (40 ms).

The host system must be able to switch off the RS-485 driver within 10 ms (20 ms) after the command was finished. The host interface must set the RS-485 to a definite state when the driver is switched off.

Note: Please read the Technical Documentation of the devices using this protocol to check if there is any kind of limitation (e.g. supported baud rate).

2 Abbreviations and formats

- F - If 1st character: Header character for dynamic data read request & response.
- G - If 1st character: Header character for static data read request & response.
- X - If 1st character: Header character for static data write request & response.
- Y - If 1st character: Header character for dynamic data write request & response.
- AC - Multiplexer (e.g. VPI) board address and channel, 8-bit hex value, 00H...FFH, ASCII coded, always 2 characters. Hex value letter characters must be in uppercase format, i.e. 'A'...'F'.
 - Bit 7...3 - Multiplexer board address (0 = board address 1, 31 = board address 32)
 - Bit 2...0 - Multiplexer channel (0 = channel 1, 7 = channel 8)
- D - Device type (a...w), always 1 lower case character, ASCII coded.
- SN - Decimal positive integer value with variable field width, ASCII coded, representing the serial number of a device. In a message dialogue, the ID '#' precedes the SN, making up the "serial number data field": <# SN>. Note: if the "serial number data field" is required, it must directly follow the "Device type" (D) character.

- N...N - Decimal integer value with variable field width, ASCII coded, all negative values have a '-' as prefix, all positive values (including 0) have no prefix. A value of -0 indicates that due to an error this value is currently not available.
- X...X - Hex value with variable field width, ASCII coded. Hex value letter characters have to be in uppercase format, i.e. 'A'...'F'. A value of "-0" indicates that due to an error this value is currently not available.
- cs - Checksum
To be able to detect messages that have been corrupted during the transmission a CRC16 checksum is included in the request and response messages. The polynomial that is used for the CRC calculation is of type CRC_CCITT ($X^{16} + X^{12} + X^5 + 1$). The seed (start value) of the CRC calculation is 0. CRC calculation starts with the first character of the message and ends with (and includes) the character directly in front of the first checksum character.
In the request message only the lower byte of the 2-byte checksum is transmitted while in the response message the complete checksum is included. The checksum is ASCII coded. Hex value letter characters must be in uppercase format, i.e. 'A'...'F'.
- cr - Carriage Return (ASCII 13dec)

3 Message dialogues

All device types that the protocol can handle support static and dynamic data. The protocol defines static data requests and dynamic data requests to read and write these two sets of data.

If probes are connected via a VPI board there are two possible configurations.

Probes of different device type on one VPI board channel

In this case the "standard" requests can be used as it is sufficient to address the VPI board, the VPI channel and the device type to address an individual probe.

Probes of the same device type on one VPI channel

In this case the "serial number data field" has to be additionally included in both, request and response of the message dialogue. Each device has a unique serial number which allows to differentiate probes of the same device type connected to a common VPI channel.

In the following a request / response message including the "serial number data field" is called an "Optional" request / response.

Probes connected directly (without VPI)

If the probes are directly connected (e.g. in case of TORRIX RS485) the multiplexer board address and channel (AC) must still be included in both, request and response of the message dialogue. In this case use multiplexer board address 1 and multiplexer channel 1, resulting in an AC value of 00H.

3.1 General message structure

Message structure: <G or F or X or Y> <AC> <D> [<data_field_1> ... <data_field_n>] <:> <cs...cs> <cr>

The need for any data fields depends on the message type.

Each data field consists of an identifier (= ID) followed by a value: <<ID_1><Value_1>>.

The colon character <:> indicates the checksum to follow.

The carriage return character <cr> represents the end of the message.

3.2 Static data

There are message dialogues for reading and writing static data. These dialogues are described in the following sub-chapters.

3.2.1 Read static data

The device that receives a static data read request will send a static data read response that contains all static data fields (<ID><Value>) supported by the device.

Static data read request

Standard static data read request:

G AC D : cs cs cr

Example:

Board Address = 1, Channel = 2 → AC = 01H
Device Type = 'a'

G 0 1 a : 2 A cr

47H, 30H, 31H, 61H, 3AH, 32H, 41H, 0DH

Optional static data read request: (like "Standard", but including the "serial number data field")

G AC D # SN : cs cs cr

Example:

Board Address = 1, Channel = 2 → AC = 01H
Device Type = 'a', Serial Number = 34594

G 0 1 a # 3 4 5 9 4 : 6 5 cr

47H, 30H, 31H, 61H, 23H, 33H, 34H, 35H, 39H, 34H, 3AH, 36H, 35H, 0DH

Static data read response

Standard static data read response:

G AC D <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

Optional static data read response: (like "Standard", but including the "serial number data field")

G AC D # SN <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

3.2.2 Write static data

The static data write request is used to write new values into one or more static data fields of the addressed device. If a received static data field is writable and the received value for this data field is within the defined valid range the device will overwrite the existing value with the new value. In the static data write response, the device will include all static data IDs that have been received. The values returned are the current values of the device.

Note that most devices will not respond to a static data write request and also that most of the static data fields are read-only.

Response if "execution not possible"

Depending on the devices' UDP protocol implementation, the device will respond in a way saying that it has received the "Static data write request" but the write access to regarded variable / data field cannot be executed. In this case the device will return the regarded data field with the requested ID followed by a value of "minus zero" (-0).

Static data write request

Standard static data write request:

X AC D <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cr

Example:

Board Address = 17, Channel = 8 → AC = 87H

Device Type = 'o'

write data field "*Hold Time After Communication Loss*": ID = 'h', value = 120 sec

write data field "*Option Flags*": ID = 'o', value = 0EH

(meaning: Maintenance Mode = 0, Output action after hold time = 1, Relay mode = 1, Relay delay = 1)

X 8 7 o h 1 2 0 o 0 E : 9 0 cr

58H, 38H, 37H, 6FH, 68H, 31H, 32H, 30H, 6FH, 30H, 45H, 3AH, 39H, 30H, 0DH

Optional static data write request:

X AC D # SN <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cr

Example:

Board Address = 18, Channel = 3 → AC = 8AH

Device Type = 'o'

read data field "*Serial number*": ID = '#', value = 4327

write data field "*Hold Time After Communication Loss*": ID = 'h', value = 0 sec

write data field "*Option Flags*": ID = 'o', value = 04H

(meaning: Maintenance Mode = 0, Output action after hold time = 0, Relay mode = 1, Relay delay = 0)

X 8 A o # 4 3 2 7 h 0 o 0 4 : B A cr

58H, 38H, 41H, 6FH, 23H, 34H, 33H, 32H, 37H, 68H, 30H, 6FH, 30H, 34H, 3AH, 42H, 41H, 0DH



Static data write response

Standard static data write response:

X AC D <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

Optional static data write response:

X AC D # SN <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

3.3 Dynamic data

There are message dialogues for reading and writing dynamic data. These dialogues are described in the following sub-chapters.

3.3.1 Read dynamic data

The device that receives a dynamic data read request will send a dynamic data read response that contains all dynamic data fields (<ID><Value>) supported by the device.

Dynamic data read request

Standard dynamic data read request:

F AC D : cs cs cr

Example:

Board Address = 1, Channel = 3 → AC = 02H
Device Type = 'b'

F 0 2 b : 6 2 cr

46H, 30H, 32H, 62H, 3AH, 36H, 32H, 0DH

Optional dynamic data read request:

F AC D # SN : cs cs cr

Example:

Board Address = 2, Channel = 6 → AC = 0DH
Device Type = 'b', Serial Number = 44389

F 0 D b # 4 4 3 8 9 : 1 D cr

46H, 30H, 44H, 62H, 23H, 34H, 34H, 33H, 38H, 39H, 3AH, 31H, 44H, 0DH

Dynamic data read response

Standard dynamic data read response:

F AC D <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

Optional read dynamic data read response:

F AC D # SN <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

3.3.2 Write dynamic data

The dynamic data write request is used to write new values into one or more dynamic data fields of the addressed device. If a received dynamic data field is writable and the received value for this data field is within the defined valid range the device will overwrite the existing value with the new value. In the dynamic data write response, the device will include all dynamic data IDs that have been received. The values returned are the current values of the device.

Note that most devices will not respond to a dynamic data write request and also that most of the dynamic data IDs are read-only.

Response if "execution not possible"

Depending on the devices' UDP protocol implementation, the device will respond in a way saying that it has received the "Dynamic data write request" but the write access to regarded variable / data field cannot be executed (e.g. the variable is unknown or currently not available). In this case the device will return the regarded data field with the requested ID followed by a value of "minus zero" (-0).

Dynamic data write request

Standard dynamic data write request:

Y AC D <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cr

Example:

Board Address = 17, Channel = 8 → AC = 87H
 Device Type = 'o'
 write data field "Channel Data": ID = 'c', value = 1

Y 8 7 o c 1 : E 4 cr

59H, 38H, 37H, 6FH, 63H, 31H, 3AH, 45H, 34H, 0DH

Optional dynamic data write request: (like "Standard", but including the "serial number data field")

Y AC D # SN <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cr

Example:

Board Address = 18, Channel = 3 → AC =
 Device Type = 'o', Serial Number = 3731
 write data field "Channel Data": ID = 'c', value = 0



Y 8 A o # 3 7 3 1 c 0 : 4 9 cr

59H, 38H, 41H, 6FH, 23H, 33H, 37H, 33H, 31H, 63H, 30H, 3AH, 34H, 39H, 0DH

Dynamic data write response

Standard dynamic data write response:

Y AC D <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

Optional dynamic data write response: (like "Standard", but including the "serial number data field")

Y AC D # SN <ID1> <VALUE1> ... <IDn> <VALUEn> : cs cs cs cs cr

4 Device types

The different device types that the protocol can handle are identified by a unique device type ID.

The following table shows the currently defined device types.

Device type IDs	
ID	Description
'a' 61H	VISY-Stick or TORRIX ... Available since protocol version: 1.00
'b' 62H	VISY-Stick/Reed Interstitial Available since protocol version: 1.00
'c' 63H	VISY-Stick/Reed Sump Manhole Available since protocol version: 1.00
'd' 64H	VISY-Stick/Reed Sump Dispenser Available since protocol version: 1.00
'e' 65H	VISY-Stick Density Only Available since protocol version: 1.00
'f' 66H	VISY-Stick Oil Separator Available since protocol version: 1.01
'g' – 'h'	Free for future expansions.
'i' 69H	VISY-Input Available since protocol version: 1.06
'j' – 'n'	Free for future expansions.
'o' 6FH	VISY-Output Available since protocol version: 1.06
'p' 70H	Pressure Sensor Available since protocol version: 1.04
'q' – 'r'	Free for future expansions.
's' 73H	VISY-Sludge Available since protocol version: 1.08
't' 74H	VISY-Temp Available since protocol version: 1.09
'u' – 'w'	Free for future expansions.

5 Data fields

Each data field consists of an ID directly followed by the value for this ID: <ID><Value>. Currently the characters ‘=’, ‘#’ and ‘a’ to ‘w’ are defined as data field IDs. In the future, it might be possible that this range will be expanded by special characters like “%”.

Notes on interpreting data fields:

The sequence and number of the data fields (consisting of ID and value) in the response messages is not fixed.

Exception: Serial number data field. If the serial number data field is included, it follows directly the device type character (D) and its meaning is common for both, static and dynamic data responses.

Static and dynamic data responses use the same IDs but with different meaning.

If unknown IDs are present in a response message these IDs and the corresponding values should be ignored.

The field width of the individual values is not fixed. So, when interpreting a response message, the field width of a certain value results out of the number of characters between the corresponding ID and the next ID or ‘:’ character that directly follows the value.

A value of -0 indicates that due to an error this value is currently not available (e.g. defective temperature sensor).

5.1 Static data fields

Static data fields are reported in the response to a static data read request. In general, the static data are read-only. Variables / data fields that are writable have a special note in the description.

The following table shows the currently defined static data fields.

Static data fields	
ID	Data field Description
‘#’ 23H	<p>Serial Number</p> <p>This data field represents the serial number of the device.</p> <p>Resolution: 1</p> <p>Valid range: 1 – 16777215</p> <p>Example: A serial number of 431725 is transferred as 34H, 33H, 31H, 37H, 32H, 35H.</p> <p>Device types: all</p> <p>Available since protocol version: 1.00</p>
‘a’ – ‘c’	Free for future expansions.

Static data fields	
ID	Data field Description
'd' 64H	<p>Position Of Density Module This data field represents the position of a density module mounted on the probe tube.</p> <p>Resolution: 1 mm</p> <p>Valid range: 0 - 65535 mm</p> <p>Example: A position of 250 mm is transferred as 32H, 35H, 30H.</p> <p>Device types: VISY-Stick (device type ID = 'a'), VISY-Stick Density Only (device type ID = 'e')</p> <p>Available since protocol version: 1.00</p> <p>Notes: This data field is only supported if the probe is equipped with at least one density module.</p> <p>If the probe is equipped with more than one density module, this data field is included more than once in the response message. In this case the position of the module with the highest mounting position (nearest to the head of the probe) is always transferred first and the position of the module with the lowest mounting position is transferred last. The measurement values of the density modules are transferred in the same sequence as their corresponding mounting positions.</p>
'e' – 'g'	<p>Free for future expansions.</p>
'h' 68H	<p>Hold Time After Communication Loss The hold time after communication loss defines if and when an output reacts after a communication loss has occurred.</p> <p>Resolution: 1 sec</p> <p>Valid range: 0 - 240 sec</p> <p>Example: A hold time of 120 sec is transferred as 31H, 32H, 30H.</p> <p>Device types: VISY-Output (device type ID = 'o')</p> <p>Available since protocol version: 1.06</p> <p>Notes: For device type VISY-Output this data field is writable.</p> <p>If the hold time is set to 0 the output will keep the last status that it had before the communication loss occurred.</p> <p>For further information about the hold time please also see the Technical Documentation of the output device.</p>
'i' – 'k'	<p>Free for future expansions.</p>

Static data fields	
ID	Data field Description
'l' 6CH	<p>Probe Length</p> <p>This data field represents the length of the probe.</p> <p>Resolution: 1 mm</p> <p>Valid range: 0 - 65535 mm</p> <p>Example: A probe length of 15000 mm is transferred as 31H, 35H, 30H, 30H, 30H.</p> <p>Device types: all</p> <p>Available since protocol version: 1.00</p>
'm' – 'n'	Free for future expansions.

Static data fields	
ID	Data field Description
<p>'o' 6FH</p>	<p>Option Flags The option flags can be used to configure an output / a relay to adopt its function to the requirements of the application.</p> <p>This ID is bit based (bit 0 - bit 7).</p> <p style="padding-left: 40px;"><u>Bit 0 - Maintenance mode</u> = 0 → Maintenance mode off = 1 → Maintenance mode on</p> <p style="padding-left: 40px;"><u>Bit 1 - Output action after hold time</u> = 0 → Output will be deactivated = 1 → Output will be activated</p> <p style="padding-left: 40px;"><u>Bit 2 - Relay mode</u> = 0 → Standard mode = 1 → Failsafe mode</p> <p style="padding-left: 40px;"><u>Bit 3 - Relay delay</u> = 0 → Relay delay off = 1 → Relay delay on</p> <p style="padding-left: 40px;"><u>Bit 4...7 - free for future expansions</u></p> <p>Format: XX (00H...FFH)</p> <p>Example: When the bits are set like this: bit 0 = 0, bit 1 = 1, bit 2 = 1, bit 3 = 1 and bits 4...7 = 0 (unused) then 30H, 45H will be transferred.</p> <p>Device types: VISY-Output (device type ID = 'o')</p> <p>Available since protocol version: 1.06</p> <p>Notes: For device type VISY-Output this data field is writable.</p> <p>For further information about the option flags please also see the Technical Documentation of the output device.</p>
<p>'p' 70H</p>	<p>Protocol Version This data field represents the version of this protocol that is implemented in the device.</p> <p>Format: XX XX (00H...FFH . 00H...FFH)</p> <p>Example: A protocol version of 01.07 (01H . 07H) is transferred as 30H, 31H, 30H, 37H.</p> <p>Device types: all</p> <p>Available since protocol version: 1.00</p>
<p>'q' – 'r'</p>	<p>Free for future expansions.</p>

Static data fields	
ID	Data field Description
's' 73H	<p>Maximun Distance</p> <p>This data field represents the maximum distance that the sensor VISY-Sludge can measure.</p> <p>Resolution: 1 mm</p> <p>Valid range: 0 - 65535 mm</p> <p>Example: A maximum distance of 1000 mm is transferred as 31H, 30H, 30H, 30H.</p> <p>Device types: VISY-Sludge (device type ID = 's'),</p> <p>Available since protocol version: 1.08</p>
't' 74H	<p>Position Of Temperature Sensor</p> <p>This data field represents the mounting position of a temperature sensor within a probe.</p> <p>Resolution: 1 mm</p> <p>Valid range: 0 - 65535 mm</p> <p>Example: A position of 2850 mm is transferred as 32H, 38H, 35H, 30H.</p> <p>Device types: VISY-Stick (device type ID = 'a'), VISY-Stick Density Only (device type ID = 'e') VISY-Temp (device type ID = 't')</p> <p>Available since protocol version: 1.00</p> <p>Note: This data field is only supported if the probe is equipped with at least one discrete temperature sensor.</p> <p>This data field can be included more than once in the response message depending on the number of temperature sensors. In this case the position of the temperature sensor with the lowest mounting position (nearest to the foot point of the probe) is always transferred first and the position of the temperature sensor with the highest mounting position is transferred last. The measurement values of the temperature sensors are transferred in the same sequence as their corresponding mounting positions.</p>

Static data fields	
ID	Data field Description
'u' 75H	<p>Device Sub-Type The device sub-type is a supplement to the device type that describes the specific characteristic of the device.</p> <p>The following sub-types are currently defined:</p> <p>For device type VISY-Stick (device type ID = 'a')</p> <ul style="list-style-type: none"> • 1 – Basic • 2 – Standard • 3 – Advanced • 4 – Flex <p>available since protocol version: 1.00</p> <p>For device types VISY-Stick/ Reed Interstitial (device type ID = 'b'), VISY-Stick/ Reed Sump Manhole (device type ID = 'c') and VISY-Stick/ Reed Sump Dispenser (device type ID = 'd')</p> <ul style="list-style-type: none"> • 1 – Stick based (magnetostrictive) • 2 – Reed based (reed switches) <p>available since protocol version: 1.00</p> <p>For device type VISY-Stick Density Only (device type ID = 'e')</p> <ul style="list-style-type: none"> • 1 – Basic • 2 – Standard • 3 – Advanced <p>available since protocol version: 1.00</p> <p>For device type Pressure Sensor (device type ID = 'p')</p> <ul style="list-style-type: none"> • 1 – VPS-V • 2 – VPS-L • 3 – VPS-T <p>VPS-V and VPS-L available since protocol version: 1.05 VPS-T available since protocol version: 1.07</p>
'v' 76H	<p>Firmware Version This data field represents the firmware version of the device.</p> <p>Format: XX XX XX XX (00H...FFH . 00H...FFH . 00H...FFH . 00H...FFH)</p> <p>Example: A firmware version of 17.5.1.255 (11H . 05H . 01H . FFH) is transferred as 31H, 31H, 30H, 35H, 30H, 31H, 46H, 46H.</p> <p>Device types: all</p> <p>Available since protocol version: 1.00</p>
'w'	<p>Free for future expansions.</p>

5.2 Dynamic data fields

Dynamic data fields are reported in the response to a dynamic data read request. In general, the dynamic data are read-only. Writable data fields have a special note in the description.

The following table shows the currently defined dynamic data fields.

Dynamic data fields	
ID	Description
'=' 3DH	<p>Status Of Device This data field represents the status of the device.</p> <p>The following values are currently defined:</p> <ul style="list-style-type: none"> 0 – OK, the device is working well 1 – Error, the device has detected an internal error and is not working well <p>Device types: all</p> <p>Available since protocol version: 1.02</p> <p>Notes: If the status of the device is not reported to be '0' this should be handled as an error.</p> <p>If the status of the device is reported to be '1' then no further data IDs will be included in the dynamic data response.</p>
'a' 61H	<p>Alarm This data field represents an alarm that the device wants to report.</p> <p>The following alarms are currently defined:</p> <p>For device types</p> <ul style="list-style-type: none"> VISY-Stick/ Reed Interstitial (device type ID = 'b') VISY-Stick/ Reed Sump Manhole (device type ID = 'c') VISY-Stick/ Reed Sump Dispenser (device type ID = 'd') <ul style="list-style-type: none"> 1 – Tamper alarm (only VISY-Stick based probes) 2 – Fuel alarm (only VISY-Stick based probes) 3 – High level alarm (only VISY-Reed based probes) 4 – Low level alarm (only VISY-Reed based probe of probe type 'b') <p>available since protocol version: 1.00</p> <p>Notes: This data field is only included in the response message if there is at least one active alarm.</p> <p>In case of multiple active alarms, each active alarm will be represented by its own alarm data field in the message.</p>

Dynamic data fields	
ID	Description
'b' 62H	<p>Battery Status This data field represents the status of the battery located in the wireless transmitter.</p> <p>Resolution: 1</p> <p>Valid range: 0 – 5</p> <ul style="list-style-type: none"> • 0 = unknown • 1...5 = very low ... very high <p>Example: A battery status of 3 is transferred as 33H.</p> <p>Device types: VISY-Stick (device type ID = 'a')</p> <p>Available since protocol version: 1.00</p> <p>Note: This data field is only supported if the device is connected wireless.</p>
'c' 63H	<p>Channel Data This data field represents the current status of a single input or output.</p> <p>Resolution: 1</p> <p>Valid range: 0 – 1</p> <ul style="list-style-type: none"> • 0 = inactive • 1 = active <p>Device types: VISY-Input (device type ID = 'i') and VISY-Output (device type ID = 'o')</p> <p>Available since protocol version: 1.06</p> <p>Note: For device type VISY-Output (device type ID = 'o') this data field is writable.</p>

Dynamic data fields	
ID	Description
'd' 64H	<p>Density This data field represents the measured density value.</p> <p>Resolution: 0.1 g/l</p> <p>Valid range: 0 – 9999.9 g/l</p> <p>Example: A density of 769.8 g/l is transferred as 37H, 36H, 39H, 38H.</p> <p>Device types: VISY-Stick (device type ID = 'a') VISY-Stick Density Only (device type ID = 'e')</p> <p>Available since protocol version: 1.00</p> <p>Notes: This data field is only supported if the probe is equipped with at least one density module.</p> <p>If the probe provides multiple density values, each density value will be represented by its own data field in the message.</p>
'e' 65H	<p>Event This data field represents an event that the device wants to report.</p> <p>The following events are currently defined:</p> <p>For device type VISY-Stick (device type ID = 'a')</p> <ul style="list-style-type: none"> • 1 – Start-Up (reduced measuring accuracy) • 2 – Filling detected <p>available since protocol version: 1.00</p> <p>For device type VISY-Sludge (device type ID = 's')</p> <ul style="list-style-type: none"> • 1 – Start-Up or no current distance value available <p>available since protocol version: 1.08</p> <p>Notes: This data field is only included in the response message if there is at least one active event.</p> <p>In case of multiple active events, each active event will be represented by its own data field in the message.</p>

Dynamic data fields	
ID	Description
'f' 66H	<p>Field Strength This data field represents the receive field strength that the wireless receiver has measured.</p> <p>Resolution: 1</p> <p>Valid range: 0 – 5</p> <ul style="list-style-type: none"> • 0 = unknown • 1...5 = very low ... very high <p>Example: A field strength of 4 is transferred as 34H.</p> <p>Device types: VISY-Stick (device type ID = 'a')</p> <p>Available since protocol version: 1.00</p> <p>Note: This data ID is only supported if the device is connected wireless.</p>
'g' – 'h'	Free for future expansions.
'i' 69H	<p>Pressure This data field represents the measured pressure/vacuum.</p> <p>Resolution: depends on the Device Sub-Type of the Pressure Sensor</p> <ul style="list-style-type: none"> • VPS-V and VPS-T: 1 μbar (0.1 Pa) • VPS-L: 1 mbar (100 Pa) <p>Valid range: not limited, depends on the used sensor</p> <p>Example for VPS-V and VPS-T: A pressure of 14.763 mbar (1476.3 Pa) is transferred as 31H, 34H, 37H, 36H, 33H.</p> <p>Example for VPS-L: A pressure of 2.861 bar (2861 hPa) is transferred as 32H, 38H, 36H, 31H.</p> <p>Device types: Pressure Sensor (device type ID = 'p')</p> <p>Available since protocol version: 1.04 (corrected in 1.07)</p> <p>Notes: 0 Pa and all positive pressures are transferred without leading '+' character.</p>
'j' – 'n'	Free for future expansions.

Dynamic data fields	
ID	Description
<p>'o' 6FH</p>	<p>Age Of Data This data field indicates how old the data is.</p> <p>Resolution: 1 sec</p> <p>Valid range: 1 – 604800 sec (1 week)</p> <p>Example: If the age of data is 384 sec 33H, 38H, 34H will be transferred.</p> <p>Device types: VISY-Stick (device type ID = 'a')</p> <p>Available since protocol version: 1.00</p> <p>Note: This Data ID is only supported if the device is connected wireless.</p>
<p>'p' 70H</p>	<p>Product Level This data field represents the level of the product.</p> <p>Resolution: 1 µm</p> <p>Valid range: 0 – 65535 mm</p> <p>Example: A Product Level of 1367.5 mm is transferred as 31H, 33H, 36H, 37H, 35H, 30H, 30H.</p> <p>Device types: VISY-Stick (device type ID = 'a') VISY-Stick Oil Separator (device type ID = 'f')</p> <p>Available since protocol version: 1.00</p> <p>Notes: For probes of device type VISY-Stick (device type ID = 'a') to get the real surface level of the product a correction must be done as the real level depends on the density of the product. For device type VISY-Stick Oil Separator (device type ID = 'f') this Data ID represents the level at the interface between oil and water.</p>
<p>'q' – 'r'</p>	<p>Free for future expansions.</p>
<p>'s' 73H</p>	<p>Distance This data field represents the distance measured from the bottom of the sensor VISY-Sludge to the reflection surface.</p> <p>Resolution: 0.1 mm</p> <p>Valid range: 0 – 65535 mm</p> <p>Example: A distance of 243.7 mm is transferred as 32H, 34H, 33H, 37H.</p> <p>Device types: VISY-Sludge (device type ID = 's')</p> <p>Available since protocol version: 1.08</p>

Dynamic data fields	
ID	Description
't' 74H	<p>Temperature This data field represents the temperature.</p> <p>Resolution: 0.001 °C</p> <p>Valid range: -99.999 – 999.999 °C</p> <p>Example: A temperature of -14.2 °C is transferred as 2DH, 31H, 34H, 32H, 30H, 30H</p> <p>Device types: VISY-Stick (device type ID = 'a') VISY-Stick Density Only (device type ID = 'e') Pressure Sensor (device type ID = 'p') VISY-Sludge (device type ID = 's') VISY-Temp (device type ID = 't')</p> <p>Available since protocol version: 1.00</p> <p>Notes: 0.000 °C and all positive temperatures are transferred without leading '+' character.</p> <p>This data ID can be included more than once in the response message if the device supports more than one temperature sensor.</p>
'u' – 'v'	Free for future expansions.

Dynamic data fields	
ID	Description
'w' 77H	<p>Water Level This data field represents the level of water.</p> <p>Resolution: 0.1 mm</p> <p>Valid range: 0 – 65535 mm</p> <p>Example: A water level of 51.0 mm is transferred as 35H, 31H, 30H.</p> <p>Device types: VISY-Stick (device type ID = 'a') VISY-Stick/ Reed Interstitial (device type ID = 'b') VISY-Stick/ Reed Sump Manhole (device type ID = 'c') VISY-Stick/ Reed Sump Dispenser (device type ID = 'd')</p> <p>Available since protocol version: 1.00</p> <p>Notes: This data field is only included in the response message if the device is equipped with a water float.</p> <p>For probes of device type VISY-Stick (device type ID = 'a') to get the real surface level of the water a correction must be done as the real level depends on the density of the product.</p> <p>For VISY-Stick based probes of device type IDs 'b', 'c' and 'd' this data field represents a general liquid level and not stringently a water level.</p> <p>For VISY-Reed based probes of device type IDs 'b', 'c' and 'd' this Data field is not included in the response message.</p>

6 Attachment A – CRC calculation

The following routines demonstrate how the CRC calculation could be done.

C routine

```

unsigned int CalcCRC16(unsigned char* data, unsigned int len) {
unsigned int i, j, x16, crc;
unsigned char input;

    crc = 0; // crc start value
    for (i = 0; i < len; i++) {
        input = *(data++); // get next data
        for (j = 0; j < 8; j++) {
            if ((crc & 0x0001) ^ (input & 0x01)) // determine the x16 value
                x16 = 0x8408; // generator polynomial
            else
                x16 = 0x0000;
            crc = crc >> 1; // shift crc
        }
    }
}

```

```
        crc = crc ^ x16;                // xor in the x16 value
        input = input >> 1;           // shift input for next iteration
    }
}
return(crc);
}
```



Pascal function

(With "array of char")

```
function TForm1.CalcCRC16(data: array of char; count: word): word;
var
  i : integer;
  crclow, crchigh : byte;
  j, k : word;
begin
  crclow := 0;
  crchigh := 0;
  for i := 0 to (count - 1) do begin
    j := crclow xor Word(data[i]);
    k := ((j shr 4) xor j) and $000f;
    j := (j and $000f) OR (k shl 4);
    crclow := Byte((crchigh xor (j shl 3)) xor k);
    crchigh := Byte(j xor (k shr 1));
  end; // for
  result := Word((crchigh * 256) + crclow);
end;
```

(With "string")

```
function TForm1.CalcCRC16(data: string; count: word): word;
var
  i : integer;
  crclow, crchigh : byte;
  j, k : word;
begin
  crclow := 0;
  crchigh := 0;
  for i := 1 to count do begin
    j := crclow xor Word(data[i]);
    k := ((j shr 4) xor j) and $000f;
    j := (j and $000f) OR (k shl 4);
    crclow := Byte((crchigh xor (j shl 3)) xor k);
    crchigh := Byte(j xor (k shr 1));
  end; // for
  result := Word((crchigh * 256) + crclow);
end;
```

Visual Basic function

```
Public Function getChkCrc16(ByVal strText As String) As UShort
Dim i, j, ii, x16, crc As UShort
Dim Input As Byte

'= for the XOR we need an array of byte. So let's convert it here.
Dim chrData() As Char = strText.ToCharArray
Dim bytData() As Byte
ReDim bytData(chrData.Length - 1)

Try
  For ii = 0 To chrData.Length - 1
    bytData(ii) = Convert.ToByte(chrData(ii))
  Next

  ii = 0                                ' Index to bytData
  crc = 0                                ' crc start value (seed)
  For i = 0 To bytData.Length - 1
    Input = bytData(i)                  ' get next data byte
    For j = 0 To 7
      If ((crc And &H1) Xor (Input And &H1)) Then 'determine the x16 value
        x16 = &H8408                    ' generator polynom
      Else
        x16 = &H0
      End If
      crc = crc >> 1                    ' shift crc
      crc = crc Xor x16                  ' XOR with the generator polynome or zero
      Input = Input >> 1
    Next
  Next

Catch ex As Exception
  crc = &H1234
  MessageBox.Show("Error: " & ex.Message)
End Try
Return crc
End Function
```



7 Attachment B – Supported data fields

The following tables show which device supports which static and dynamic data fields.

Static data fields

Supported Static Data IDs sorted by Device Type											
Device Type	Device Sub-Type 'u'	Serial Number '#'	Firmware Version 'v'	Protocol Version 'p'	Probe Length 'l'	Maximum Distance 's'	Position Of Temperature Sensor 't'	Position Of Density Module 'd'	Hold Time 'h'	Option Flags 'o'	Alarm Pressure 'a'
VISY-Stick (a)	yes	yes	yes	yes	yes	no	yes	no/yes *1	no	no	no
VISY-Stick Interstitial (b)	yes	yes	yes	yes	yes	no	no	no	no	no	no
VISY-Reed Interstitial (b)	yes	yes	yes	yes	yes	no	no	no	no	no	no
VISY-Stick Sump Manhole (c)	yes	yes	yes	yes	yes	no	no	no	no	no	no
VISY-Reed Sump Manhole (c)	yes	yes	yes	yes	yes	no	no	no	no	no	no
VISY-Stick Sump Dispenser (d)	yes	yes	yes	yes	yes	no	no	no	no	no	no
VISY-Reed Sump Dispenser (d)	yes	yes	yes	yes	yes	no	no	no	no	no	no
VISY-Stick Density Only (e)	yes	yes	yes	yes	yes	no	yes	yes	no	no	no
VISY-Input (i)	no	yes	yes	yes	no	no	no	no	no	no	no
VISY-Output (o)	no	yes	yes	yes	no	no	no	no	yes *2	yes *2	no
Pressure Sensor (p)	yes	yes	yes	yes	no	no	no	no	no	no	no
VISY-Sludge (s)	no	yes	yes	yes	no	yes	no	no	no	no	no
VISY-Temp (t)	no	yes	yes	yes	no	no	yes	no	no	no	no
VIMS (v)	yes	yes	yes	yes	no	no	no	no	no	no	yes

NOTE: In general all Static Data IDs are read-only.

yes	always supported
no	never supported
no/yes *1	only supported if at least one density module is mounted
yes *2	this Data ID is writable

Dynamic data fields

Supported Dynamic Data IDs sorted by Device Type											
Device Type	Status Of Device 's'	Product Level 'p'	Water Level 'w'	Distance 's'	Temperature 't'	Density 'd'	Pressure 'i'	Alarm 'a'	Event 'e'	Channel Data 'c'	Tightness Indicator 's'
VISY-Stick (a)	yes	yes	yes/no *2	no	yes	no/yes *3	no	no	yes	no	no
VISY-Stick Interstitial (b)	yes	no	yes *1	no	no	no	no	yes	no	no	no
VISY-Reed Interstitial (b)	yes	no	no	no	no	no	no	yes	no	no	no
VISY-Stick Sump Manhole (c)	yes	no	yes *1	no	no	no	no	yes	no	no	no
VISY-Reed Sump Manhole (c)	yes	no	no	no	no	no	no	yes	no	no	no
VISY-Stick Sump Dispenser (d)	yes	no	yes *1	no	no	no	no	yes	no	no	no
VISY-Reed Sump Dispenser (d)	yes	no	no	no	no	no	no	yes	no	no	no
VISY-Stick Density Only (e)	yes	no	no	no	yes	yes	no	no	no	no	no
VISY-Input (i)	yes	no	no	no	no	no	no	no	no	yes	no
VISY-Output (o)	yes	no	no	no	no	no	no	no	no	yes *4	no
Pressure Sensor (p)	yes	no	no	no	yes	no	yes	no	no	no	no
VISY-Sludge (s)	yes	no	no	yes	yes	no	no	no	yes	no	no
VISY-Temp (t)	yes	no	no	no	yes	no	no	no	no	no	no
VIMS (v)	yes	no	no	no	no	no	yes	yes	yes	no	yes

NOTE: In general all Dynamic Data IDs are read-only.

yes	always supported
no	never supported
yes *1	in this case the Data ID represents a general liquid level
yes/no *2	not supported if no water float is mounted
no/yes *3	only supported if at least one density module is mounted
yes *4	this Data ID is writable