Configuration chart VISY-Setup V 3.1GB and above

This chart is a summary of the required VISY-Setup configuration steps depending on the different host systems.

The first row indicates the minimum version of VISY-Setup depending on the different configuration steps.

The first column indicates the minimum version of VISY-Command depending on the different host systems.

Configuration step VISY-Setup V 3.x / V 4.x	Available since VISY-Command Version	**Menu Control unit (F2)**	Host	Communication adress	Expansion port	Wireless mode	Wireless timeout	**Date and time (F3)**	**Menu Probes (F4)**	Ser.-Nr. of the probe	Fixed Offset of the probe	Type of product (F4)	Product designation	Product code	Alarm configuration	**Menu Tank contents tables (F5)**	Reference temperature	Permissible filling rate	Build tank contents table	**Serial port**	Baud rate	Data bits	Parity	Stop bits
Host																								
Available since VISY-Setup Version			1.01	1.01	1.01	3.1	3.1	2.10		1.01	1.01	1.01	1.01	1.01	2.10		1.01	1.01	1.01					
Adrus	1.04		105		V	W	W			X	X	X					X	X	X		9600	7	O	1
Airlog	1.00		104		V	W	W			X	X	X									300	8	N	1
Aladin	1.00		103		V	W	W			X	X	X					V	V	X		1200	8	N	1
Autopoll - 300 Baud	3.11		113		V	W	W			X	X	X					X	X	X		300	8	N	1
Autopoll - 1200 Baud	3.11		114		V	W	W			X	X	X					X	X	X		1200	8	N	1
Autotank Petropoint	3.14		111		V	W	W	X		X	X	X		X	X		X	X	X		2400	7	E	1
Avalon 9600 Baud	1.04		105		V	W	W			X	X	X					X	X	X		9600	7	O	1
Avalon 1200 Baud	2.07		110		V	W	W			X	X	X					X	X	X		1200	7	O	1
B crtl-A	3.15		116		V	W	W			X	X	X	(1)						X		2400	7	E	1
Dresser Wanye Marketer 2000/2500/3000	1.00		101		V	W	W			X	X	X									1200	8	N	1
Dresser Wayne Nucleus	1.00		101		V	W	W			X	X	X									1200	8	N	1
Dresser Wanye EuroSinp	3.11		115		V	W	W	X		X	X	X		O	O		O	O	O		9600	8	N	1
DOMS PSS 5000	3.01		111		V	W	W	X		X	X	X		X	X		X	X	X		2400	7	E	1
DOS Task Technology TS50/TS5000	1.03		101		V	W	W			X	X	X									1200	8	N	1
Enraf 867 Emulation (Level)	3.16		118		V	W	W			X	X	X									1200	8	N	1
Enraf 867 Emulation (Volume)	3.16		119		V	W	W			X	X	X					V	V	X		1200	8	N	1
EPSI Interface	1.04		106		V	W	W			X	X	X					O	O	O		9600	8	N	1
Finnpos	1.00		101		V	W	W			X	X	X									1200	8	N	1
Gilbarco CEM-44	3.11		115		V	W	W	X		X	X	X		O	O		O	O	O		9600	8	N	1
Gilbarco CEM-44 (Deliveries)	4.1.2		121		V	W	W	X		X	X	X	O	O	O		X	X	X		9600	8	N	1
Gilbarco Passport Europe	3.02		112		V	W	W	X		X	X	X		O	O		X	X	X		9600	7	O	1
GIR Software and Devices	3.11		113		V	W	W			X	X	X					X	X	X		300	8	N	1
HecStar / HecFleet	4.1.4		122		V	W	W	X		X	X	X	O	O	O		X	X	X		9600	7	N	1
Huth T400/T450 (Level)	1.00		101		V	W	W			X	X	X									1200	8	N	1
Huth T400/T450 (Volume)	1.00		102		V	W	W			X	X	X					V	V	X		1200	8	N	1
IFSF LON Interface	2.00		107		V	W	W			X	X	X					O	O	O		9600	8	N	1
ITL Enabler	3.11		115		V	W	W	X		X	X	X		O	O		O	O	O		9600	8	N	1
Lafon Magic	1.04		105		V	W	W			X	X	X					X	X	X		9600	7	O	1
Maser Gestok	1.00		100		V	W	W			X	X	X									1200	8	N	1
MCD Monitor	1.04		105		V	W	W			X	X	X					X	X	X		9600	7	O	1
mcdTank MS	2.06		109		V	W	W			X	X	X					X	X	X		9600	7	O	1
MICRELEC	1.00		101		V	W	W			X	X	X									1200	8	N	1
Minerve	1.00		104		V	W	W			X	X	X									300	8	N	1
MODBUS ASCII	4.2.0		123	X	V	W	W			X	X	X			O		O	O	O		9600	8	N	1
MODBUUS RTU	4.2.0		124	X	V	W	W			X	X	X			O		O	O	O		9600	8	N	1
MODBUS TCP	4.2.0		125	X	V	W	W			X	X	X			O		O	O	O		9600	8	N	1
NCR	4.2.7		128		V	W	W	X		X	X	X	O	O	O		X	X	X		9600	8	N	1
NSYS PoS	4.1.2		121		V	W	W	X		X	X	X	O	O	O		X	X	X		9600	8	N	1
Orpak SiteOmat controller	4.1.2		121		V	W	W	X		X	X	X	O	O	O		X	X	X		9600	8	N	1
OTAS-Plus 4.00	1.00		101		V	W	W			X	X	X									1200	8	N	1
PEC 8850	3.15		116		V	W	W			X	X	X	(1)						X		2400	7	E	1
Postec PCC	3.11		115		V	W	W	X		X	X	X		O	O		O	O	O		9600	8	N	1
Retailix IPPOS	3.15		117		V	W	W	X		X	X	X		O	O		X	X	X		2400	7	O	1
S&B Master 10/20 (Level)	1.00		100		V	W	W			X	X	X									1200	8	N	1
S&B Master 10/20 (Volume)	1.00		102		V	W	W			X	X	X					V	V	X		1200	8	N	1
S&B TA 220 (Level)	1.00		100		V	W	W			X	X	X									1200	8	N	1
S&B TA 220 (Volume)	1.00		102		V	W	W			X	X	X					V	V	X		1200	8	N	1
S&B OPT 230 stand alone (Level)	1.00		100		V	W	W			X	X	X									1200	8	N	1
S&B OPT 230 stand alone (Volume)	1.00		102		V	W	W			X	X	X					V	V	X		1200	8	N	1
Technotrade PTS Controller	4.0.4		108		V	W	W			X	X	X					X	X	X		9600	8	N	1
Tokheim FuelPOS	3.02		112		V	W	W	X		X	X	X		O							9600	7	O	1
Tokheim KCD	1.00		101		V	W	W			X	X	X									1200	8	N	1
Tokheim Omega 2000 (German version)	1.02		101		V	W	W			X	X	X									1200	8	N	1
Tripod	3.16		108		V	W	W	X		X	X	X	X		O		X	X	X		9600	8	N	1
Unicode	3.01		111		V	W	W	X		X	X	X		X	X		X	X	X		2400	7	E	1
Veeder-Root DIS-50 / DIS-51	4.0.7		120		V	W	W	X		X	X	X	X		X		X	X	X		9600	8	N	2
Veeder-Root Insite360	4.2.2		126		V	W	W	X		X	X	X	O	O	O		X	X	X		9600	7	E	1
VISY-Monitor	3.13		108		V	W	W			X	X	X									9600	8	N	1
VISY-Quick	2.04		108		V	W	W	X		X	X	X	X		O		X	X	X		9600	8	N	1
VISY-Tank	3.00		108		V	W	W	X		X	X	X	X		O		X	X	X		9600	8	N	1
VISY-View	2.04		108		V	W	W	X		X	X	X	X		O		X	X	X		9600	8	N	1

(1): 1st and 2nd letter of product designation are conform to grade ID

X: Configuration mandatory

O: Configuration optional

V: Opional if VISY-View, VISY-View Touch or GUI at expansion port

W: Required for wireless operation

Edition: 09/06/2020

Article no.: 350080