

Configuration chart VISY-Setup V 3.1GB and above

This chart is a summary of the required VISY-Setup configuration steps depending on the different host systems. The first row indicates the minimum version of VISY-Setup depending on the different configuration steps. The first column indicates the minimum version of VISY-Command depending on the different host systems.																									
Configuration step VISY-Setup V 3.x / V 4.x	Available since VISY-Command Version																								
		Menu Control unit (F2)	Host	Communication address	Expansion port	Wireless mode	Wireless timeout	Date and time (F3)	Menu Probes (F4)	Ser.-Nr. of the probe	Fixed Offset of the probe	Type of product (F4)	Product designation	Product code	Alarm configuration	Menu Tank contents tables (F5)	Reference temperature	Permissible filling rate	Build tank contents table	Serial port	Baud rate	Data bits	Parity	Stop bits	
Host	Available since VISY-Setup Version		1.01	1.01	1.01	3.1	3.1	2.10		1.01	1.01	1.01	1.01	1.01	2.10		1.01	1.01	1.01						
Adrus	1.04	105		V	W	W			X	X	X					X	X	X			9600	7	O	1	
Airlog	1.00	104		V	W	W			X	X	X										300	8	N	1	
Aladin	1.00	103		V	W	W			X	X	X					V	V	X			1200	8	N	1	
Autopoll - 300 Baud	3.11	113		V	W	W			X	X	X					X	X	X			300	8	N	1	
Autopoll - 1200 Baud	3.11	114		V	W	W			X	X	X					X	X	X			1200	8	N	1	
Autotank Petropoint	3.14	111		V	W	W	X		X	X	X		X	X		X	X	X			2400	7	E	1	
Avalon 9600 Baud	1.04	105		V	W	W			X	X	X					X	X	X			9600	7	O	1	
Avalon 1200 Baud	2.07	110		V	W	W			X	X	X					X	X	X			1200	7	O	1	
B crtI-A	3.15	116		V	W	W			X	X	X	(1)						X			2400	7	E	1	
Bungalski (Level)	1.00	101		V	D	D			X	X	X										1200	8	N	1	
Bungalski (Volume)	1.00	102		V	D	D			X	X	X				V	V	X				1200	8	N	1	
Dresser Wanye Marketer 2000/2500/3000	1.00	101		V	W	W			X	X	X										1200	8	N	1	
Dresser Wayne Nucleus	1.00	101		V	W	W			X	X	X										1200	8	N	1	
Dresser Wanye EuroSinp	3.11	115		V	W	W	X		X	X	X		O	O		O	O	O			9600	8	N	1	
DOMS PSS 5000	3.01	111		V	W	W	X		X	X	X		X	X		X	X	X			2400	7	E	1	
DOS Task Technology TS50/TS5000	1.03	101		V	W	W			X	X	X										1200	8	N	1	
Enraf 867 Emulation (Level)	3.16	118		V	W	W			X	X	X										1200	8	N	1	
Enraf 867 Emulation (Volume)	3.16	119		V	W	W			X	X	X				V	V	X				1200	8	N	1	
EPSI Interface	1.04	106		V	W	W			X	X	X				O	O	O				9600	8	N	1	
Finnpos	1.00	101		V	W	W			X	X	X										1200	8	N	1	
Gilbarco CEM-44	3.11	115		V	W	W	X		X	X	X		O	O		O	O	O			9600	8	N	1	
Gilbarco CEM-44 (Deliveries)	4.1.2	121		V	W	W	X		X	X	X		O	O	O	X	X	X			9600	8	N	1	
Gilbarco Passport Europe	3.02	112		V	W	W	X		X	X	X		O	O		X	X	X			9600	7	O	1	
GIR Software and Devices	3.11	113		V	W	W			X	X	X					X	X	X			300	8	N	1	
HecStar / HecFleet	4.1.4	122		V	W	W	X		X	X	X		O	O	O	X	X	X			9600	7	N	1	
Huth T400/T450 (Level)	1.00	101		V	W	W			X	X	X										1200	8	N	1	
Huth T400/T450 (Volume)	1.00	102		V	W	W			X	X	X				V	V	X				1200	8	N	1	
IFSF LON Interface	2.00	107		V	W	W			X	X	X				O	O	O				9600	8	N	1	
ITL Enabler	3.11	115		V	W	W	X		X	X	X		O	O		O	O	O			9600	8	N	1	
Lafon Magic	1.04	105		V	W	W			X	X	X					X	X	X			9600	7	O	1	
Maser Gestok	1.00	100		V	W	W			X	X	X										1200	8	N	1	
MCD Monitor	1.04	105		V	W	W			X	X	X					X	X	X			9600	7	O	1	
mcdTank MS	2.06	109		V	W	W			X	X	X					X	X	X			9600	7	O	1	
MICRELEC	1.00	101		V	W	W			X	X	X										1200	8	N	1	
Minerve	1.00	104		V	W	W			X	X	X										300	8	N	1	
MODBUS ASCII	4.2.0	123	X	V	W	W			X	X	X			O		O	O	O			9600	8	N	1	
MODBUUS RTU	4.2.0	124	X	V	W	W			X	X	X			O		O	O	O			9600	8	N	1	
MODBUS TCP	4.2.0	125	X	V	W	W			X	X	X			O		O	O	O			9600	8	N	1	
NCR	4.2.7	128		V	W	W	X		X	X	X		O	O	O	X	X	X			9600	8	N	1	
NSYS PoS	4.1.2	121		V	W	W	X		X	X	X		O	O	O	X	X	X			9600	8	N	1	
Orpak SiteOmat controller	4.1.2	121		V	W	W	X		X	X	X		O	O	O	X	X	X			9600	8	N	1	
OTAS-Plus 4.00	1.00	101		V	W	W			X	X	X										1200	8	N	1	
PEC 8850	3.15	116		V	W	W			X	X	X	(1)						X			2400	7	E	1	
Postec PCC	3.11	115		V	W	W	X		X	X	X		O	O		O	O	O			9600	8	N	1	
Retailix IPPOS	3.15	117		V	W	W	X		X	X	X		O	O		X	X	X			2400	7	O	1	
S&B Master 10/20 (Level)	1.00	100		V	W	W			X	X	X										1200	8	N	1	
S&B Master 10/20 (Volume)	1.00	102		V	W	W			X	X	X				V	V	X				1200	8	N	1	
S&B TA 220 (Level)	1.00	100		V	W	W			X	X	X										1200	8	N	1	
S&B TA 220 (Volume)	1.00	102		V	W	W			X	X	X				V	V	X				1200	8	N	1	
S&B OPT 230 stand alone (Level)	1.00	100		V	W	W			X	X	X										1200	8	N	1	
S&B OPT 230 stand alone (Volume)	1.00	102		V	W	W			X	X	X				V	V	X				1200	8	N	1	
Technotrade PTS Controller	4.0.4	108		V	W	W			X	X	X					X	X	X			9600	8	N	1	
Tokheim FuelPOS	3.02	112		V	W	W	X		X	X	X		O								9600	7	O	1	
Tokheim KCD	1.00	101		V	W	W			X	X	X										1200	8	N	1	
Tokheim Omega 2000 (German version)	1.02	101		V	W	W			X	X	X										1200	8	N	1	
Tripod	3.16	108		V	W	W	X		X	X	X	X		O		X	X	X			9600	8	N	1	
Unicode	3.01	111		V	W	W	X		X	X	X		X	X		X	X	X			2400	7	E	1	
Veeder-Root DIS-50 / DIS-51	4.0.7	120		V	W	W	X		X	X	X	X		X		X	X	X			9600	8	N	2	
Veeder-Root Insite360	4.2.2	126		V	W	W	X		X	X	X		O	O	O	X	X	X			9600	7	E	1	
VISY-Monitor	3.13	108		V	W	W			X	X	X										9600	8	N	1	
VISY-Quick	2.04	108		V	W	W	X		X	X	X	X		O		X	X	X			9600	8	N	1	
VISY-Tank	3.00	108		V	W	W	X		X	X	X	X		O		X	X	X			9600	8	N	1	
VISY-View	2.04	108		V	W	W	X		X	X	X	X		O		X	X	X			9600	8	N	1	

(1): 1st and 2nd letter of product designation are conform to grade ID

X: Configuration mandatory
O: Configuration optional
V: Optional if VISY-View, VISY-View Touch or GUI at expansion port
W: Required for wireless operation
Edition: 17/01/2022
Article no.: 350080